

Feb-24
8:58 AM

The following models are not supported for these models, please use PFSCT (Panasonic Security System Configuration Tool) V7.x.

Camera : WV-NP82+ , WV-NP92 , WV-NP04+ , WV-NP04 , WV-NP80 , WV-NP100+ , WV-NK99+ , WV-NT30A , WV-NT31A , WV-NW684 , BB-HCHM+ , BL-C

Recorder : WV-HD330 , WV-HC330 , WV-HD336A , WV-HD350 , WV-HC360

*1: "Camera title position" setting is not supported.
*2: "Language" , "Start Date/time" , "End Date/time" settings are not supported.
*3: "Upside-down" setting is not supported.
*4: "Image rotation" setting is not supported.
*5: "Max Bit rate" , "Smart Coding Mode" setting is not supported.
*6: "Active black stretch" , "AGC" , "DNF" settings are not supported.
*7: For the audio settings, "Unicast Port/Audio" setting is not supported.
*8: PC must be able to connect to the Internet.
*9: "QoS" setting is not supported.
*10: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models (Firmware version 1.11 or later required).
-WV-S1136 , WV-S1586L , WV-S1636LN , WV-S2136L , WV-S2236L , WV-S2536L , WV-S2536L+ , WV-S2136
If the firmware version of the camera is 1.4 or higher, please use version 2.3 or higher of this software.
Audio input encoding format* and Audio volume control mode* are not supported.
-WV-S1550S , WV-S1570S , WV-S2250S , WV-S2270S , WV-S2550S and WV-S2570S , WV-S2260S , WV-S2550S
Firmware version 1.01 or higher required
Audio input encoding format and *Audio volume control mode* are not supported.
*11: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models (Firmware version 1.50 or later required. Some video and audio settings require camera firmware version 1.60 or higher.).
If the firmware version of the camera is 1.6 or higher, please use version 2.3 or higher of this software.
Audio input encoding format and *Audio volume control mode* are not supported.
-WV-X1551L , WV-X1571LN , WV-X2251L , WV-X2271L , WV-X2551LN , WV-X2571LN
-WV-X1570-V2L , WV-X2270S-V2L , WV-X2270S-V2LM , WV-X1560S-V2L , WV-X2560S-V2L , WV-X1530S-V3L , WV-X2230S-V3L , WV-X2530S-V3L , WV-X1550S-V3L , WV-X2250S-V3L , WV-X2550S-V3L
*12: Corresponds to the Extension system settings of the following models (Starts from the thumbnail menu on the main screen.)
-WV-S4176 , WV-S4536(L)M , WV-S4176 , WV-S4536(L)M , WV-S7130-F3
*13: After "Application update" completion, please re-confirm the setting value / schedule settings and check the operation application.
*14: Please refer the following.
http://www.panasonic.co.jp/english/support/faq/index.html#faq_03101

*15: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models.
-WV-U81300-ZY , WV-U81301-ZY , WV-U6300-ZY , WV-U6301-ZY , WV-U6302-ZY , WV-U6302-ZZ , WV-S65501-ZY , WV-S61501-ZY
*16: You can launch the "Extension Application by thumbnail menu. This function supports the following models.
-WV-S8543(L) , WV-S8544(L) , WV-S8563L , WV-S8564L , WV-S8573 , WV-S8574L , WV-X8631-ZZ and WV-X8630-ZZ , WV-S85702-F3L , WV-S85402-V2L
*17: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models.
-WV-S7130-F3
*18: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models.
-WV-U1130A , WV-U1132A , WV-U1142A , WV-U1523LA , WV-U1542LA , WV-U2130LA , WV-U2132LA , WV-U2140LA , WV-U2142LA , WV-U2530LA , WV-U2532LA , WV-U2540LA , WV-U2542LA , WV-U85402-V2L , WV-U11300-V2 , WV-U21300-V2L , WV-U21301-F2L , WV-U1401-F2L , WV-U1301-F2L , WV-U1301-F2L , WV-U35401-F2L
*19: "App. Updater" is not supported.
*20: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models.
-WV-S4156 , WV-S4176 , WV-S4566(M) , WV-S4576(M)
*21: You can launch the "Camera Advanced Settings" function by thumbnail menu. This function supports the following models. "Upside-down" and/or "Image rotation" setting is not supported.
-WV-S6340-Z4K , WV-S6340-Z4M , WV-S6340-Z4K , WV-S6340-Z4M , WV-S61301-Z2 , WV-S61301-Z2 , WV-S61301-Z2
-WV-S2302-F2L , WV-S3302-F2L , WV-X3302-F2L , WV-S61602-Z3 , WV-S61702-Z3 , WV-S66300-Z3L , WV-S66300-Z3 , WV-S66300-Z3L , WV-S66600-Z3 , WV-S66600-Z3L , WV-S66700-Z3 , WV-S66700-Z3L , WV-S66300-Z3 , WV-S66300-Z3L , WV-S66300-Z4L , WV-S66600-Z4L , WV-S66600-Z4L , WV-S66600-Z4L , WV-S66700-Z3L , WV-S66700-Z3L
-WV-S2402-F3L , WV-S35402-F3L , WV-X35402-F2L
*22: JPEG still images cannot be acquired with the following model when the imaging mode is 50/60fps.
-WV-X15600-V2L , WV-X22600-V2L , WV-S25600-V2L , WV-X15700-V2L , WV-X22700-V2L , WV-X25700-V2L , WV-X15500-V3L , WV-X22500-V3L , WV-X25500-V3L
*23: For the following model, when the Image Rotation is changed from other than 90°/270° to 90°/270°, the camera will restart.
-WV-X15300-V3L , WV-X22300-V3L , WV-S25300-V3L , WV-X15600-V2L , WV-X22600-V2L , WV-X25600-V2L , WV-X15700-V2L , WV-X22700-V2L , WV-X25700-V2L , WV-X15500-V3L , WV-X22500-V3L , WV-X25500-V3L
*24: For the following model, when the Intrae Capture Mode is changed from a mode other than 50/60fps to 50/60fps, the camera will restart.
-WV-X15300-V3L , WV-X22300-V3L , WV-S25300-V3L , WV-X15600-V2L , WV-X22600-V2L , WV-X25600-V2L , WV-X15700-V2L , WV-X22700-V2L , WV-X25700-V2L , WV-X15500-V3L , WV-X22500-V3L , WV-X25500-V3L
*25: If you update the firmware of the recorder and the camera connected to the "PC port" on the back of the recorder at the same time, the camera firmware update may fail.
In this case, update the recorder and camera firmwares separately.
*26: In 50/60fps mode, H.264 stream (1) video may show black on some cameras. You can check the video stream by temporarily switching the stream settings to H.265.