



< How to replace the dome cover >

■ When replacing the dome cover, use the dome cover sheet provided with the camera.

- ① Remove the dome cover sheet attached to the dome cover.
- ② Remove the two claws of the enclosure (see the lower left illustration) one by one by widening the enclosure to the outside.
- ③ Remove the dome cover by lifting it from the outside of the enclosure.
- ④ Attaching the new dome cover.
- ⑤ Attach the dome cover sheet provided with the camera to the new dome cover.



<ドームカバーの交換について>

■ドームカバーを交換するときは、カメラに付属しているドームカバーシートを使用してください。

- ①ドームカバーに貼られているドームカバーシートをはがす。
- ②エンクロージャーの爪のうちの2か所（下左図参照）を、エンクロージャーを外側に広げるようにして1か所ずつ外す。
- ③ドームカバーをエンクロージャーの外側から持ち上げて取り外す。
- ④新しいドームカバーを取り付ける。
- ⑤カメラに付属しているドームカバーシートを貼り付ける。

