

WJ-NXF02*1 Operating Instructions

New functions and revisions (Software V4.60)

*1 WJ-NXF02, WJ-NXF02W

The WJ-NXF02 will be able to provide the following new functions by updating the software.

It also contains the latest information related to the Operating Instructions.

Details on the new functions and revisions	Reference pages						
<p>Addition/deletion of description Set up face matching alarm [Face matching] - [Usage pattern]</p> <p>Note:</p> <ul style="list-style-type: none"> ● <u>When using the camera only with this product, be sure to use "Non-shared".</u> ● <u>When "Share" is selected, the settings related to face matching will not be set on the camera, so set the camera directly if necessary.</u> ● Some camera cannot be used with other devices. ● When selecting "Share", directly set up the camera as required. ● The settings are subject to [Usage pattern] of statistical processing function. 	Page 11						
<p>Addition of description Troubleshooting</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Symptom</th> <th style="text-align: left;">Cause/solution</th> <th style="text-align: center;">Ref. pages</th> </tr> </thead> <tbody> <tr> <td style="vertical-align: top;"> <p>Even if the face matching alarm is set to On, the face matching alarm is not detected.</p> <p>Statistical processing does not work even if the statistical processing setting is set to On.</p> </td> <td style="vertical-align: top;"> <p>Is the usage pattern setting set to "Share"? If you want to use the camera only with this product, set the usage mode to "Non-shared" and set the face matching alarm and statistical processing.</p> </td> <td style="text-align: center; vertical-align: top;">11</td> </tr> </tbody> </table>	Symptom	Cause/solution	Ref. pages	<p>Even if the face matching alarm is set to On, the face matching alarm is not detected.</p> <p>Statistical processing does not work even if the statistical processing setting is set to On.</p>	<p>Is the usage pattern setting set to "Share"? If you want to use the camera only with this product, set the usage mode to "Non-shared" and set the face matching alarm and statistical processing.</p>	11	Page 26
Symptom	Cause/solution	Ref. pages					
<p>Even if the face matching alarm is set to On, the face matching alarm is not detected.</p> <p>Statistical processing does not work even if the statistical processing setting is set to On.</p>	<p>Is the usage pattern setting set to "Share"? If you want to use the camera only with this product, set the usage mode to "Non-shared" and set the face matching alarm and statistical processing.</p>	11					