# **III·PRO**

## Major Operating Controls and Their Functions




## Wall Mount Bracket Operating Instructions Model No. WV-Q154C WV-Q154CE WV-Q154S WV-Q154SE

Before attempting to connect or operate this product, please read these instructions carefully and save this manual for future use

The model number is abbreviated in some descriptions in this manual.

Ns1010-6042 3TR006649GZA Printed in China



#### Note:

• Remove the notch with a nipper.

Wall box

• If a microphone is used, mount the microphone on the rubber-made microphone stand. Unless the microphone is used, cut the rubber with a nipper or conduct another treatment.

## **Installation Area**

Instructions for installing the machine and a wiring example are given below.

\* The pull-out strength of the installation area shall be 392 N {40 kgf} or more per 1 screw.

### Embedded box

Strong wall

## Preface

This wall mount bracket is exclusively designed to mount the network camera. Refer to the catalog or the installation guide of the camera for supported cameras.

The network camera shall be mounted on this bracket after mounting this bracket on a concrete wall.

• WV-Q154C: Clear dome cover

• WV-Q154S: Smoked dome cover (approx. 50 % of transmittance)

## **Precautions**

#### • Refer installation work to the dealer.

Installation work requires technique and experiences. Be sure to refer installation work to the dealer to avoid fire, electric shock, injury, or damage to the product.

• Avoid installing this bracket in the locations where salt damage occurs or corrosive gas is produced.

Otherwise, the mounting portions will deteriorate and accidents such as a fall of the camera may occur.

• Use only the specified camera.


Failure to observe this may cause a fall of an inappropriate camera resulting in injury or accidents. Refer to the catalog or the installation guide of the camera for supported cameras.


- The screws and fixation mechanisms shall be tightened securely. Failure to observe this may cause a fall of the camera resulting in injury or accidents.
- The measures of protection against a fall of the camera shall be taken. Failure to observe this may cause injury. Be sure to install this bracket-specific safety wire.
- · Select an installation area that can support the total weight.


If a selected area is too weak to support the total weight, a fall of the product may occur resulting in injury. Installation work shall be started after sufficient reinforcement.

#### • Periodic inspections shall be conducted.

Rust on the metal parts or screws may cause a fall of the camera resulting in injury or accidents. Be sure to consult the dealer for the inspections.








## Installations

Be sure to read "Precautions" before installation. The Installation Guide of the network camera shall be read as well.

1. Put the template (accessory) against the wall and mark the positions of fixing screws and hole through which the cables run.

If you run the cables through the wall, drill a hole through the wall.




- Do not rub the edges of metal parts with your hand. Failure to observe this may cause injury.
- Make sure that the installation area is strong enough to hold the total weight of the camera assembly (approx. 1.8 kg {0.4 lbs.}) before installation.
- The screws that secure this bracket on a wall are not supplied. Prepare the screws according to the material, structure, strength and other factors of the mounting area and the total weight of objects to be mounted. (4 pieces of M4 screws or 2 pieces of M4 screws and 2 pieces of M6 or M8 anchor bolts) In this case, wood screws and nails should not be used.
- Avoid installing in the following locations.
  - Locations where it may get wet from rain or water splash (not only outdoor)
  - Locations where a chemical agent is used such as a swimming pool
  - Locations subject to steam and oil smoke such as a kitchen
  - Locations near flammable gas or vapor
  - Locations where radiation or x-ray emissions are produced
  - Locations subject to strong magnetic field or radio waves
  - Locations where it may be damaged by briny air such as seashores
  - Locations where the temperature is not within –10 °C +50 °C {14 °F 122 °F}
  - Locations subject to vibrations (This product is not designed for on-vehicle use.)
  - Locations where the temperature may rapidly change such as the peripheral areas of the air outlets of air conditioners or doors facing outside. (In case of installing the camera in such locations, the dome cover may become foggy or condensation may be caused on the cover.)
- The screws and bolts must be tightened with an appropriate tightening torque according to the material and strength of the installation area. After tightening the screws or bolts, perform visual check to ensure tightening is enough and there is no backlash.
- The pull-out strength of the installation area shall be 392 N {40 kgf} or more per 1 screw.
- The protection sheet attached to the dome cover shall be peeled off after installation.

#### 2. Remove the bottom cover from this bracket.

- ① Loosen the fixing screw (unremovable) to be used for cover fall prevention.
- ② Pull down the bottom cover while pressing the marks (shown with ➡ in the drawing) to remove the cover.

**Note:** Be aware that the inner shell is present in the cover.




Fixing screw to be used for cover fall prevention


(To be continued reverse page)

## Installations (continued)

#### 3. Install the inner cover.

- Slide the covers located on the both lateral sides of the camera and put the inner cover on the camera until the hooks inside the inner cover are held in the holes of the camera (until a click is heard).
- Important: Put the inner cover down on the camera until the outside cover of the camera cannot be seen from the opening (from which the camera lens is visible) of the inner cover. If this integration is not successfully performed, the inner cover may be removed or the hidden part at the top of the screen may become larger in the WIDE mode.





#### How to remove the inner cover

Press the inner cover from the front and rear sides inward (at the same vertical position as the hooks) to bend the cover and remove the shell from the camera.

# Press from the front and rear sides inward to bend Y


#### 4. Mount the top cover on the wall and run the cables.

Secure the top cover in either of the following two ways: 1) and 2). No screw is supplied. Procure screws according to the installation area.

① M4 screws, 4 positions (a) or

- 2 M4 screws, 2 positions ((a) upper 2 positions, not available in lower positions) and M6 or M8 anchor bolts, 2 positions (b)
- Important: The length of the anchor bolt projecting portion (the distance between the tip of the anchor bolt and the chassis attaching surface) shall be 7 mm {1/4"} or less. Failure to observe this causes interference between the anchor bolt and bottom cover. Therefore, the bottom cover cannot be mounted

## (a) (a) 0 (b) (a) (a)



#### 5. Mount the camera.

Refer to the Installation Guide of network camera for further information. The camera mounting bracket is already

attached to this bracket at the time of purchase. Make sure to use the provided mount bracket.

Important: When mounting the camera, push the camera securely into the mounting section of the top cover.

# Note: When the camera is pointed in the horizontal direction, the upper side of the screen is hidden. Refer to the Operating Instructions (PDF) of network camera for further information.

## **Specifications**


Ambient temperature: Dimensions:


Mass: Finish: -10 °C to +50 °C {14 °F to 122 °F} 165 (W) x 206.5 (H) x 217.5 (D) mm {6-1/2 inches (W) x 8-1/3 inches (H) x 8-9/16 inches (D)} Approx. 950 g {2.10 lbs} Main body: Treatment steel Top and bottom covers: ABS resin with silver metallic coating Dome cover: Acrylic resin

## **Standard Accessories**

Operating Instructions (this book) ..... 1 pc.

The following are for installation.		
Template	1	sheet
Inner cover	1	pc.






Safety wire

Camera fixing screw (accessory of the network camera)

#### 6. Mount the bottom cover.

Be sure to push the bottom cover up until a click is heard.

Important: Do not let the cables be caught during installation work.



For U.S. and Canada:

i-PRO Americas Inc.

For Europe and other countries: i-PRO EMEA B.V.

https://www.i-pro.com/

7. Tighten the fixing screw to be used for cover fall prevention.

Recommended tightening torque: 1.6 N·m {16 kgf·cm}

© i-PRO Co., Ltd. 2022