# Application Note

# For i-PRO Network Camera

For  $ONVIF^{\ensuremath{\$}}$  Profile T / Profile S / Profile G / Profile M

Ver. 1.1

i-PRO Co., Ltd.

ONVIF is a trademark of ONVIF, Inc.

# **Revision History**

Ver.	Date	Chapter #	Comment	Trigger
			Reword.	
1.1	2024/01/1	6.2.10	Added note on multi-sensor cameras in Analytics	
			Configuration	
1.0	2022/10/24		first edition	

# **Copyright Notice**

This document is copyright protected and i-PRO Co., Ltd. reserves all titles and rights in the document. Nobody can copy, reproduce, distribute, or modify this document in any way without the prior written consent of i-PRO Co., Ltd..

# Index

1.	Intro	oduc	tion	. 8
1	.1.	Defi	nitions	. 8
2.	Ger	neral		. 9
2	.1.	"Us	er name/Password" setup now required upon first time access	. 9
2	.2.	Inde	ЭХ	. 9
3.	Dev	vice c	liscovery	10
3	.1.	Sco	pe	10
	3.1.	1.	SetScopes, AddScopes	10
4.	Dev	vice s	ervice	11
4	.1.	Net	work	11
	4.1.	1.	SetHostname	11
	4.1.	2.	SetDNS	11
	4.1.	3.	SetNTP	11
	4.1.	4.	SetDynamicDNS	12
	4.1.	5.	SetNetworkInterfaces	12
	4.1.	6.	SetNetworkProtocols	13
	4.1.	7.	SetNetworkDefaultGateway	13
	4.1.	8.	SetZeroConfiguration	14
4	.2.	Sec	urity	15
	4.2.	1.	Username token	15
	4.2.	2.	TLS	16
4	.3.	Inpu	ut/Output	17
	4.3.	1.	SetRelayOutputSettings	17
5.	Ima	ging	Service	18
5	.1.	WD	and BLC	18
5	.2.	Nati	ve Setting and GetImagingSettings parameter binding	19
	5.2.	1.	ToneCompensation and Defogging	23
6.	Me	dia se	ervice	27
6	.1.	Prof	file	27
	6.1.	1.	Share Profile with ONVIF and native settings	27
	6.1.	2.	Profile Name	31
	6.1.	3.	Stream	31
6	.2.	Con	figuration	32
	6.2.	1.	Note for configuration changes	32
	6.2.	2.	"RateControl" Parameters	32
				4

	6.2	.3.	"Multicast" Parameter	33
	6.2	.4.	"SessionTimeout" Parameter	34
	6.2	.5.	"GovLength" Parameter	34
	6.2	.6.	Metadata Configuration	35
	6.2	.7.	Audio Back Channel Configuration	36
	6.2	.8.	"Quality" Parameter	37
	6.2	.9.	"Rotate" Parameter	37
	6.2	.10.	Analytics Configuration	38
6	6.3.	OSE	D	39
	6.3	.1.	Maximum number of OSD	39
	6.3	.2.	Position	39
6	6.4.	Vide	eoSourceMode	40
7.	Stre	eamir	ng	41
7	7.1.	Ses	sion Management	41
7	7.2.	Frar	nerate	41
7	7.3.	Bac	k Channel Connection	42
7	7.4.	Rela	ationship with Cropping feature	44
7	7.5.	Net	vork failure trigger base SD backup	45
8.	PTZ	Z Ser	vice	46
8	3.1.	Use	case of PTZ	47
	8.1	.1.	Set PTZ configuration	47
	8.1	.2.	PTZ control	47
	8.1	.3.	Home Position	47
	8.1	.4.	Zoom	48
	8.1	.5.	Wiper, Washer, IR-LED	49
	8.1	.6.	Generic Space	53
	8.1	.7.	Speed settings	53
9.	Eve	ent se	rvice	54
ç	9.1.	Noti	fication Events	54
ç	9.2.	The	number of event registration	55
ç	9.3.	How	<i>i</i> to use event	55
	9.3	.1.	Terminal alarm	55
	9.3	.2.	Motion alarm	57
	9.3	.3.	Command alarm	58
	9.3	.4.	Remaining capacity of the SD memory card	58
10.	Red	cordir	ng Service	59
	0.1.	How	- / to use	59
	10.	1.1.	Activation for storage feature	59
1	0.2.	Bitra	ate Limit and GovLength	59
			-	

10.3. Recording procedure	60
10.4. Multi-sensor camera recording specifications	60
11. Search Service	61
11.1. Search filter for FindEvent	61
12. Replay Service	62
12.1. Replay Session	62
12.2. Procedure for playing back recordings	62
12.3. RTSP URL Format	62
12.4. RTSP Header	63
13. Media2 Service	64
13.1. Profile	64
13.1.1. Share Profile with ONVIF and native settings	64
13.1.2. Profile Name	67
13.1.3. Stream	67
13.2. Configuration	68
13.2.1. Note for configuration changes	68
13.2.2. "RateControl" Parameters	68
13.2.3. "Multicast" Parameter	68
13.2.4. "SessionTimeout" Parameter	68
13.2.5. "GovLength" Parameter	68
13.2.6. "Metadata" Configuration	69
13.2.7. "Audio Back Channel" Configuration	69
13.2.8. "Quality" Parameter	
13.2.9. "Rotate" Parameter	71
13.2.10. Analytics Configuration	71
13.3. OSD	71
13.3.1. Maximum number of OSD	71
13.4. VideoSourceMode	71
14. Analytics Service	72
14.1. How to use	72
14.2. List of supported functions	72
14.3. Analytics Mudule Type and Rule Type	73
14.3.1. Kinds for Analytics Modules	73
14.3.2. Kinds for Rule	73
14.3.3. FieldDetector	74
14.3.4. LineDetector	77
14.3.5. LoiteringDetector	80
14.3.6. MotionRegionDetector	
14.3.7. DirectionDetector	

14.4.	RuleName naming rule	
14.5.	Fixed camera, multi-sensor camera	
14.8	5.1. PTZ camera	
15. Met	adata Stream	
15.1.	Metadata Stream Format	
15.2.	ONVIF RTSP Stream	
15.2	2.1. MetadataStream support status list	
15.2	2.2. MetadataStream distribution sequence	
15.3.	i-PRO original RTSP Stream	
15.3	3.1. MetadataStream support status list	
15.3	3.2. MetadataStream distribution sequence	
I. Hov	v to use Event service	
A)	Receive push type events (WS-BaseNotification)	
i.	Flow of receiving Motion Detect Event	
ii.	Example of SOAP trace	100
B)	Get pull type events (Event service of ONVIF)	
i.	Flow of receiving Motion Detect Event	
ii.	Example of SOAP trace	112
II. Abc	but i-VMD	116
A)	Analytics Service	116
i.	How to use	116
B)	Metadata Stream	116
i.	ONVIF RTSP Stream	116
ii.	i-PRO original RTSP Stream	117

# 1. Introduction

This document describes the ONVIF application guide for i-PRO network camera. It mentions some clues to integrate the i-PRO network camera through ONVIF interface.

This document doesn't give an explanation of ONVIF specification itself and the information using the ONVIF interface. Please refer to i-PRO network camera operating instruction manual as well.

# 1.1. Definitions

Term	Description
	Organizations promoting standardization of communication between IP-based physical
	security products
	ONVIF specification are published on the ONVIF website.
	Setting that is standard installed in a camera that can be controlled without going
	through ONVIF. Native settings are operated from the http(s):// (IP address) / setting
Native setting	screen or IP Camera –Command Interface.
	This document does not describe detailed methods and contents of Native setting.
	Please see the Network Camera Operation Instruction Manual, CGI Instruction Manual.
	A browser is a web setting screen. The screen that displays the IP address of the
	camera on a web browser and moves to the setting screen is described as a browser.
Browser	The sentence "Please change parameter A via the browser" means "Please change
	the value of parameter A on the web setting screen of the camera", that is, "Please
	change the value of parameter A of the native settings"

# 2. General

# 2.1. "User name/Password" setup now required upon first time access

Please register user name / password from the browser.

ONVIF connection becomes possible after user name password setting.

# 2.2. Index

The specification for ONVIF chapter **Device discovery** 3 4 **Device service** 5 **Imaging Service Media service** 6 7 Streaming **PTZ Service** 8 **Event service** 9 10 **Recording Service Search Service** 11 12 **Replay Service** 13 Media2 Service 14 **Analytics Service** Metadata Stream 15

List of specifications described in this document:

# 3. Device discovery

# 3.1.Scope

# 3.1.1.SetScopes, AddScopes

The maximum number of Scope is 20.

Corresponding default scope:

default scope	Description
onvif://www.onvif.org/Profile/G onvif://www.onvif.org/Profile/M onvif://www.onvif.org/Profile/Streaming onvif://www.onvif.org/Profile/T	Indicates ONVIF Profile support status. The supported Protile varies depending on the model.
onvif://www.onvif.org/hardware/(model)	(model) is the model number of the camera.
onvif://www.onvif.org/location/office	Fixed string "office"
onvif://www.onvif.org/name/i- PRO_(model)	(model) is the model number of the camera.

# 4. Device service

# 4.1.Network

### 4.1.1.SetHostname

If hostname is set through DHCP after setting with this command, it will be overwritten. Hostname will be set by the latest operation of manual setting or DHCP setting.

### 4.1.2.SetDNS

The network camera can have up to 2 DNS addresses for IPv4 and up to 2 DNS addresses for IPv6, total 4 addresses. If more than 4 addresses are set, they will be ignored.

Regarding DHCPv6 only getting IP address function is available, getting DNS (v6) address is not supported. Client need to set the DNS manually.

When the camera is set to DHCP mode and fromDHCP flag of SetDNS is true, manually setting IP address will be ignored.

### 4.1.3.SetNTP

Only one NTP address is available. If there are more than one address in SetNTP, the excess of that will be ignored.

As there is no definition of NTP port number in ONVIF specification, the following way to set the port number can be available in i-Pro camera.

```
IPv4Address = "10.0.0.100:234"
IPv6Address = "[2001:12:34:56::1]:234"
DNSName = "ntp.test.co.jp:234"
```

Application Note For i-PRO Network Camera

### 4.1.4.SetDynamicDNS

TSIG is not supported.

In ServerUpdate, DHCPv6 (RFC4704) is not supported.

### 4.1.5.SetNetworkInterfaces

#### 4.1.5.1. MTU

MTU value cannot be changed. Client receive an error if the value other than 1500 is set.

#### 4.1.5.2. IPv4

IPv4 address cannot be disabled. If client set

IPv4 - Enabled = false

Camera will return an error.

The number of IPv4 address set manually is one. If further address is set, it will be ignored.

#### 4.1.5.3. IPv6

IPv6 address cannot be disabled. If client set

IPv6 - Enabled = false

Camera will ignore the setting and return with no error (Previous values are remained).

The number of IPv6 address set manually is one. If further address is set, it will be ignored.

The prefix of the manually configured IPv6 address must be "64". The camera returns an error for other prefixes.

AcceptRouterAdvert parameter cannot be changed to "false".

Configurable values for DHCP parameter are "Stateful" or "Off", if "Stateless" or "Auto" is set to the parameter, the camera will send an error. As described in 4.1.2, this camera only supports getting IP address function, if client specify "Stateful", client will fail to get DNS address from DHCP.

### 4.1.6.SetNetworkProtocols

Either HTTP, HTTPS, HTTP + HTTPS must be set

Enable both HTTP and HTTPS

name="HTTP", Enabled = true
name="HTTPS", Enabled = true

Enable HTTPS, disable HTTP:

name="HTTP", Enabled = false
name="HTTPS", Enabled = true

Disable HTTPS, enable HTTP:

name="HTTP", Enabled = true
name="HTTPS", Enabled = false

If both HTTP and HTTPS are set to "false", the camera returns an error.

```
name="HTTP", Enabled = false
name="HTTPS", Enabled = false
```

#### 4.1.7.SetNetworkDefaultGateway

Only one default gateway address is available. If there are more than one address in this method, it will be ignored.

IPv6 address is not supported. If it is specified, camera will return error.

When a camera is in DHCP (v4) mode set by SetNetworkInterface, this camera cannot set IPv4 address manually with SetNetworkDefaultGateway. If it's specified the camera will return an error.

# 4.1.8.SetZeroConfiguration

ZeroConfiguration which is the return value of GetCapabilities () or GetServiceCapabilities () indicates correspondence to SetZeroConfiguration() and GetZeroConfiguration().

ZeroConfiguration is disabled in later firmware since Dec. 2013. The capability is informed in ZeroConfiguration.

# 4.2. Security

### 4.2.1.Username token

The camera authenticates the user ID set for the camera via a browser. The user level set in the camera via a browser applies to ONVIF user level, and vice versa.

Existing user levels and ONVIF user levels match as follow.

Native setting	User-level via a ONVIF	
Admin :	Administrator	
Control :	Operator	
Live :	User	

The following is the user authentication table for each level of commands. From the browser user can set user authentication to ON/OFF, command authentication is changed according to the setting.

	Native setting User auth. = On				Native setting User auth. = Off			
	Administ	Opera	Lleor	No-	Administ	Opera	Lloor	No-
	rator	tor	USEI	auth	rator	tor	User	auth
Administrator	Voc	No	No	No	Voc	No	No	No
command	165	NO	NO	NO	165	NO	NO	NO
Operator	Vac	Voc	No	No	Vac	Voc	Voc	Voc
command	165	Tes	NO	NO	165	Tes	Tes	165
User	Vac	Voc	Voc	No	Vac	Voc	Voc	Voc
command	165	Tes	res	INO	165	Tes	Tes	165
Anonymous	Vac	Voc	Voc	Vac	Vac	Voc	Voc	Voc
command	162	162	162	Tes	162	162	162	TES

Please refer to the "Support Command Reference Chart" for the access level of each commands.

# 4.2.2.TLS

If the key is not generated, TLS is disabled. In order to generate a self-signed certificate or a SSL Server certificate, key need to be generated in advance. User can generate the key only from browser or through CGI because  $i_{\circ}$ 

t takes some time.

Camera can have one self-signed certificate and one SSL Server certificate and TLS uses either one. If both the self-signed certificate and SSL Server certificate are valid, SSL Server certificate will be used. Client authentication is not supported.

To enable HTTPS, please set it from browser or with "SetNetworkProtocols" .

Application Note For i-PRO Network Camera

# 4.3. Input/Output

"RelayOutputs" is set to "disabled" by default, as a client can confirm this setting through "GetCapabilities" command. In order to set the RelayOutput enabled, please set Alarm-[Terminal alarm 3] to AUX output. After the setting, the value of "IO-RelayOutputs" will be changed to 1. Similarly, "InputConnectors" have to be set by the browser.

# 4.3.1.SetRelayOutputSettings

i-Pro camera allows the parameter value as follows.

Properties - Mode = Bistable Properties - IdleState = open

When other settings are specified, the camera will return an error.

# 5. Imaging Service

# 5.1.WD and BLC

Super Dynamic function (WD) and BLC are run exclusively. A camera with Super Dynamic function can be set WideDynamicRange but not BacklightCompensation. A camera without Super Dynamic function can be set BacklightCompensation but not WideDynamicRange.

# 5.2. Native Setting and GetImagingSettings parameter binding

Correspondence table between native Image adjust settings and GetImagingSettings parameter.

Native setting Image adjust*		GetImagingSettings Output	Description
Nauve Seturi	y inage aujust	parameter	Description
		Extension.	
	Stabilizer	ImageStabilization.	
Basic		Mode	
	On	ON	
	Off	OFF	
	Brightness	Brightness	
	0-255* <sup>1</sup>	0.407	
	0-127*1	0-127	
	Chroma gain level	ColorSaturation	
Dasia	0 - 255	0 - 255	
Basic	Sharpness level	Sharpness	
adjustment	0 - 31	0 - 31	
	DNR	Extension. Extension.	
		Extension.	
		NoiseReduction.Level	
	0 - 255	0.0 - 1.0	
	0	WideDynamicRange.	
	UN/UI	Mode	
Curran.	On	ON	
Super	Off	OFF	
Dynamic(S	l evel	WideDynamicRange.	NUUL when Meda is
	Levei	Level	NULL when wode is
	0.21	null or	Mode is ON
	0~31	0~31	

<sup>1</sup> Different models have different ranges of values for native settings.

Native setting Image adjust*		GetImagingSettings Output	Description	
Nalive Selli	y maye aujust	parameter	Description	
	Day & Night(IR)	IrCutFilter		
	For models with IR Light: *1			
	Off			
	On(IR Light Off)			
	On(IR Light On)			
	Auto1(IR Light Off)			
	Auto2(IR Light On)	OFF	Please refer to	
	Auto3(SCC)	ON	chapter 8.1.5.1 for the	
	For models without IR Light: *1	AUTO	setup procedure.	
	Off			
	On			
	Auto1(Normal)			
	Auto2(IR Light)			
	Auto3(SCC)			
Day &		IrCutFilterAutoAdjustme		
Night		nt. BoundaryOffset		
	*Models with the following menus <sup>*1</sup>			
	Low	-1 - 0		
	High	0 - 1		
	*Models with the following menus <sup>*1</sup>			
	0	1 – 0.5		
	1	-0.5 – 0		
	2	0.0 – 0.5		
	3	0.5 – 1.0		
	Dwall time	IrCutFilterAutoAdjustme		
		nt. ResponseTime		
	2s	PT2S		
	10s	PT10S		
	30s	PT30S		
	1min	PT60S		

Native setting Image adjust*		GetImagingSettings Output	Description
Nauve setting	j image aujust	parameter	Description
	ATW1/ATW2/AWC	WhiteBalance. Mode	
	ATW1/ATW2	AUTO	
\A/l=:t=	AWC	MANUAL	
vvnite	Red gain	WhiteBalance. CrGain	
Dalarice	0-255	0-255	
	Blue gain	WhiteBalance. CbGain	
	0-255	0-255	
		Extension. Extension. Extension.	
	Auto contrast adjust	ToneCompensation.Mode	
	On	AUTO	
	Off(Manual)	ON	
	Contract loval	Extension. Extension. Extension.	In the case of native
		ToneCompensation. Level	128,
	0-255	0.0.1.0	ToneCompensation
Detailed	0-200	0.0-1.0	Level is 0.5
	For componention	Extension. Extension. Extension.	
seung		Defogging. Mode	
	On	ON	
	Off	OFF	
		Extension. Extension. Extension.	When native is 4,
	Leve	Defogging. Level	ToneCompensation
	0~8	0.0~1.0	Level is 0.5
	Pedestal level	Contrast	
	0-255	0-255	

Image/Audio>Image quality>Image adjust

Example of GetImagingSettings response:

```
<GetImagingSettingsResponse xmlns="http://www.onvif.org/ver20/imaging/wsdl">
  <ImagingSettings>
   <tt:Brightness>64</tt:Brightness>
   <tt:ColorSaturation>128</tt:ColorSaturation>
   <tt:Contrast>128</tt:Contrast>
   <tt:Focus>
     <tt:AutoFocusMode>AUTO</tt:AutoFocusMode>
     <tt:NearLimit>1.5</tt:NearLimit>
     <tt:FarLimit>0</tt:FarLimit>
   </tt:Focus>
   <tt:IrCutFilter>AUTO</tt:IrCutFilter>
   <tt:Sharpness>16</tt:Sharpness>
   <tt:WideDynamicRange>
     <tt:Mode>ON</tt:Mode>
     <tt:Level>29</tt:Level>
   </tt:WideDynamicRange>
   <tt:WhiteBalance>
     <tt:Mode>AUTO</tt:Mode>
     <tt:CrGain>128</tt:CrGain>
     <tt:CbGain>128</tt:CbGain>
   </tt:WhiteBalance>
   <tt:Extension>
     <tt:ImageStabilization>
       <tt:Mode>OFF</tt:Mode>
     </tt:ImageStabilization>
     <tt:Extension>
       <tt:IrCutFilterAutoAdjustment>
         <tt:BoundaryType>Common</tt:BoundaryType>
         <tt:BoundaryOffset>-1</tt:BoundaryOffset>
         <tt:ResponseTime>PT10S</tt:ResponseTime>
       </tt:IrCutFilterAutoAdjustment>
       <tt:Extension>
         <tt:ToneCompensation>
           <tt:Mode>ON</tt:Mode>
           <tt:Level>0.5</tt:Level>
         </tt:ToneCompensation>
         <tt:Defogging>
           <tt:Mode>ON</tt:Mode>
           <tt:Level>0.5</tt:Level>
         </tt:Defogging>
         <tt:NoiseReduction>
           <tt:Level>0.5</tt:Level>
         </tt:NoiseReduction>
       </tt:Extension>
     </tt:Extension>
   </tt:Extension>
  </ImagingSettings>
</GetImagingSettingsResponse>
```

# 5.2.1.ToneCompensation and Defogging

#### 5.2.1.1. How Native Settings Intelligent Auto Affects ToneCompensation and Defogging

The *Intelligent Auto* setting in the native settings is linked to the *ToneCompensation* and *Defogging* settings in the Imaging settings Parameters.

#### Get=GetImagingSettings

Set=SetImagingSettings

Intelligent Auto/Native	On	Off
Auto contrast adjust/Native	Disable	Enable
	Disable	Enable
ToneCompensation	Get:No response.	Get: Response.
	Set: Ignore	Set: Enabled
Fog compensation/Native	Disable	Enable
	Disable	Enable
Defogging	Get: No response	Get: Response.
	Set: Ignore	Set: Enabled

#### Intelligent Auto is On:

(\*ToneCompensation is not responded.)
(\*Defogging is not responded.)

When *Intelligent Auto* is set to *On* in Native, *Auto contrast adjust* and *Fog compensation* in Native settings are disabled, *ToneCompensation* and *Defogging* in *ImagingSettings* are disabled. GetImagingSettings() does not return *ToneCompensation* and *Defogging*. The camera ignores this value when *ToneCompensation* and *Defogging* are specified in SetImagingSettings().

#### Intelligent Auto is Off:

```
<tt:ToneCompensation>
<tt:Mode>ON</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:ToneCompensation>
<tt:Defogging>
<tt:Mode>OFF</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:Defogging>
```

Setting *Intelligent Auto* in Native to *Off* enables *Auto contrast adjust* and *Fog compensation* in Native settings, and *ToneCompensation* and *Defogging* in *ImagingSettings*. GetImagingSettings()

Application Note For i-PRO Network Camera

returns *ToneCompensation* and *Defogging*. When *ToneCompensation* and *Defogging* are specified in SetImagingSettings(), the camera sets the specified values.

Application Note For i-PRO Network Camera

#### 5.2.1.2. Auto contrast adjust

The *Auto contrast adjust* in the native settings and the *Defogging* setting in *ImagingSettings* are linked.

Get=GetImagingSettings

Set=SetImagingSettings

Auto contrast adjust/Native	On	Off(Manual)
ToneCompensation.Mode/ONVIF	AUTO	ON
	Disable	Enable
Defogging	Get: No response.	Get: Response
	Set: Ignore	Set: Enabled

When Native's *Auto contrast adjust* is *ON* and Mode of *ToneCompensation* in *ImagingSettings* is set to AUTO:

<tt:ToneCompensation>

<tt:Mode>AUTO</tt:Mode>

<tt:Level>0.5</tt:Level>

</tt:ToneCompensation>

(\*Defogging is not responded.)

If **Auto contrast adjust** in Native is set to **ON** or Mode of *ToneCompensation.Mode* in *ImagingSettings* is set to AUTO, *Defogging* in *ImagingSettings* is disabled. GetImagingSettings() does not return *Defogging*. The camera ignores this value when *Defogging* is specified in SetImagingSettings().

When Native's Auto contrast adjust is Off (Manual) and Mode of ToneCompensation in ImagingSettings is ON:

```
<tt:ToneCompensation>
<tt:Mode>ON</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:ToneCompensation>
<tt:Defogging>
<tt:Mode>OFF</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:Defogging>
```

Setting Native's **Auto contrast adjust** to **Off (Manual)** or setting *ToneCompensation*'s *Mode* to ON will enable *Defogging* in *ImagingSettings*. *Defogging* is included in the GetImagingSettings() response. When *Defogging* is specified in SetImagingSettings(), the camera sets the specified values.

#### 5.2.1.3. Linkage of fog correction and automatic contrast adjustment

The **Fog compensation** in the native settings and the *ToneCompensation* setting in *ImagingSettings* are linked.

Get=GetImagingSettings

Set=SetImagingSettings

Fog compensation/Native	On	Off(Manual)
Defogging. Mode /ONVIF	ON	OFF
ToneCompensation.Level	Disable	Enable
	Get: Level is not added	Get: Level added
	Set: Error if ON and Level exists	Set: Enabled

#### Fog compensation is On:

```
<tt:ToneCompensation>
<tt:Mode>ON</tt:Mode>
(*Level is not responded.)
</tt:ToneCompensation>
<tt:Defogging>
<tt:Mode>ON</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:Defogging>
```

No Level is assigned at Get, and an error is returned at Set if Mode=ON and Lecel is included.

#### Fog compensation is Off

```
<tt:ToneCompensation>
<tt:Mode>ON</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:ToneCompensation>
<tt:Defogging>
<tt:Mode>OFF</tt:Mode>
<tt:Level>0.5</tt:Level>
</tt:Defogging>
```

Level is assigned on Get, and is set on Set.

# 6. Media service

# 6.1. Profile

### 6.1.1.Share Profile with ONVIF and native settings

I-Pro cameras have the following two kinds of handling of Profile.

- 1) For the following models, settings via ONVIFAPI and settings via the browser are linked
  - Models other than those listed in 2)
    - Values set with ONVIF-API are reflected in setting values viewed via browser.

Values set via the browser are reflected in ONVIF setting values.

#### Note: For details on relationships, see the next chapter.

6.1.1.1 Relationship between 'Setup/Image' of native setting and VideoencoderConfiguration.token of ONVIF

6.1.1.2 Relationship between 'Setup / Image' of native setting and ONVIF setting items

- 2) For the following models, settings via ONVIFAPI and settings via the browser are not linked
  - WV-SUD638 Series
  - The value set with ONVIF-API is not reflected in the setting value displayed in the browser. .
  - Values set via the browser are not reflected in ONVIF setting values

# 6.1.1.1. Relationship between 'Setup/Image' of native setting and VideoencoderConfiguration.token of ONVIF

The model sharing the setting with ONVIF and Native is defined in "6.1.1 Share Profile with ONVIF and native settings".

Correspondence table of ONVIF properties and browser setting menu on models in which the ONVIF Interface setting value is linked with the Native setting value viewed from the browser:

Native setting	ONVIF	
Setup > image	VideoencoderConfiguration.token	
Stream (1)	h26x_1_video	
Stream (2)	h26x_2_video	
Stream (3)	h26x_3_video	
Stream (4)	h26x_4_video	
JPEG(1)	jpeg_1_video	
JPEG(2)	jpeg_2_video	

multi-sensor cameras:

Native setting	ONVIF	
Setup > image	VideoencoderConfiguration.token	
Stream (1)	h26x_1_video	
	h26x_1_video_ch2	
	h26x_1_video_ch3	
	h26x_1_video_ch4	
	h26x_2_video	
Stroom (2)	h26x_2_video_ch2	
Stream (2)	h26x_2_video_ch3	
	h26x_2_video_ch4	
	jpeg_1_video	
JPEG(1)	jpeg_1_video_ch2	
	jpeg_1_video_ch3	
	jpeg_1_video_ch4	

#### 6.1.1.2. Relationship between 'Setup / Image' of native setting and ONVIF setting items

The model sharing the setting with ONVIF and Native is defined in "6.1.1 Share Profile with ONVIF and native settings".

As shown in the table below, the camera's existing settings and the ONVIF settings are linked

Native Setting JPEG (n)*	ONVIF setting	Description
Image capture size	Resolution	VideoEncoderConfiguration.Resolution
Image quality	Quality	VideoEncoderConfiguration. Quality
		See chapter 6.2.8"Quality" Parameter

\*Setup > Image > JPEG (n)

Native setting	ONVIE setting	Description	
stream (n)*	Old in Solaring		
		If "Stream transmission" is set to "OFF" with Native setting,	
Stream		video is not delivered even with the ONVIF profile linked with	
transmission	-	NativeSetting's Stream.	
		At this time, the value of the ONVIF profile is NOT changed.	
Stream encoding	Encoding	VideoEncoderConfiguration.Encoding	
format	Encoding	Media1 service cannot control H265.	
Image capture size	Resolution	VideoEncoderConfiguration.Resolution	
Transmission	(Media2)	Settings can be changed only from Media 2	
priority	ConstantBitRate See 13.2.2.3 "ConstantBitRate" Parameter)		
		VideoEncoderConfiguration.RateControl. FrameRateLimit	
Frame rate	FrameRateLimit	See 6.2.2.2"FramerateLimit" Parameter	
Max bit rate (per	Ditrotal imit	VideoEncoderConfiguration:.RateControl. BitrateLimit	
client)	DitrateLimit	See 6.2.2.1"BitrateLimit" Parameter	
1		VideoEncoderConfiguration. Quality	
image quality	Quality	See 6.2.8"Quality" Parameter	
Smart Coding		See 6.2.5.2"GovLength" Parameter of Smart Coding	
Refresh interval	GovLength	See 6.2.5"GovLength" Parameter	

Native setting	ONVIF setting	Description	
stream (n)*			
Transmission type	Multicast	VideoEncoderConfiguration::Multicast	
		Multicast settings is independent for ONVIF configuration	
		and native configuration.	
		The stream settings have a structure in which the native	
		settings and ONVIF Profile match, but for multicast, the	
		native settings and ONVIF work differently.	
		See 6.2.3"Multicast" Parameter	

\*Setup > Image > stream (n)

### 6.1.2. Profile Name

The standard profile name differs depending on the model.

If you use multiple cameras, use the profile name included in the GetProfiles() response instead of using a fixed profile name. The VideoSourceMode may change the configuration of the Profile.

### 6.1.3.Stream

#### 6.1.3.1. The minimum guaranteed total number of encoder instances

The number of streams that can be delivered is fixed.

GetGuaranteedNumberOfVideoEncoderInstances() reports the number of streams that can be delivered simultaneously.

#### 6.1.3.2. RTSP URL format

To get the URI of the RTSP connection, send *GetStreamUri()* specifying Profile. The URL format is as follows:

rtsp://<IP>/ONVIF/MediaInput?profile=<ProfileToken>

# 6.2. Configuration

### 6.2.1.Note for configuration changes

When a client change configuration during live streaming, the connection will be disconnected. When a bit rate of G.726 is changed, all connections will be disconnected. Set a value within the range that can be obtained with Get<configuration entity>Options.

### 6.2.2. "RateControl" Parameters

#### 6.2.2.1. "BitrateLimit" Parameter

Depending on "VideoEncoder Configuration", the ranges of the bit rate that the client can set are different.

#### JPEG:

Max = 0, Min = 0;

#### H264:

When a user sets a bit rate value besides these values, the camera adopts it the nearest value from the valid bit rate. For example, when a user sets 4000kbps, the camera will choose 3072kbps. A set of available bit rate depends on the model. The range of the available bit rate can be vary according to its resolution. Please refer to the operating instruction manual for detail.

#### Note: The camera chooses the smaller value than the bit rate that a user set.

#### 6.2.2.2. "FramerateLimit" Parameter

Frame rate values supported by the camera can be obtained from GetVideoEncoderConfigurationOptions. When a client sets a frame rate value, the camera chooses the nearest value from the specified frame rate. For example, when a client set 19fps, the camera chooses 15fps.

#### Note: The camera chooses the smaller value than the frame rate that the client set.

### 6.2.3."Multicast" Parameter

The initial value of the multicast address is shown below.

Type = IPv4 IPv4Address = 0.0.0.0 Port = 0 TTL = 0

These initial settings above mean that multicast setting is invalid.

These initial settings are recommended when a client does not use multicast. Because the camera will allocate the band width beforehand for multicast when a client enabled multicast setting (The camera's specification).

The ONVIF Multicast setting is independent of and does not affect the Native Multicast setting.

When multicasting with RTSP, the URI changes from unicast.

After setting the multicast address of MediaConfiguration, get the URI with *GetStreamUri()*. Request multicast delivery using the obtained URI.

Application Note For i-PRO Network Camera

### 6.2.4. "Session Timeout" Parameter

"SessionTimeout" parameter is fixed in the camera, and the change is not supported. A client have to use "PT120S" or "PT2M" to set. Receiving other values, the camera will return without an error and it will be ignored.

### 6.2.5."GovLength" Parameter

#### 6.2.5.1. "GovLength" Parameter of H.264

The value of "GovLength" is calculated by the following formula. Refresh interval(Native) \* Frame rate(Native) = GovLength(ONVIF) e.g. 1(sec) x 15(fps) = 15(gov)

This camera manages the following Refresh interval values.

0.2, 0.25, 0.33, 0.5, 1, 2, 3, 4, 5 (sec)

The GovLength range varies depending on the fps limit.

The GovLength setting is rounded by the camera.

Example) GovLength =149→120

#### 6.2.5.2. "GovLength" Parameter of Smart Coding

For cameras that support "smart coding", when "Smart coding" is set to "On" from the browser, the browser setting takes precedence.

- The value of GovLength is automatically rewritten, and it is reflected in the stream delivered by ONVIF.
- If you attempt to overwrite the GovLength value with the ONVIF command, an error will be returned.

# 6.2.6. Metadata Configuration

MetadataConfiguration holds the MetadataStream settings for the target Stream.

#### Response Example:

```
<tt:MetadataConfiguration token="metadata1">
   <tt:Name>MetadataConfig1</tt:Name>
   <tt:UseCount>0</tt:UseCount>
   <tt:PTZStatus>
       <tt:Status>false</tt:Status>
       <tt:Position>false</tt:Position>
   </tt:PTZStatus>
   <tt:Events>
       <tt:Filter>
           <wsnt:TopicExpression
Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"
xmlns:tns1="http://www.onvif.org/ver10/topics" xmlns:tnsipro1 = "http://i-
pro.com/2021/onvif/event/topics">
             </wsnt:TopicExpression>
           <wsnt:MessageContent
Dialect="http://www.onvif.org/ver10/tev/messageContentFilter/ItemFilter">
             </wsnt:MessageContent>
       </tt:Filter>
   </tt:Events>
   <tt:Analytics>true</tt:Analytics>
   <tt:Multicast>
       <tt:Address>
           <tt:Type>IPv4</tt:Type>
           <tt:IPv4Address>0.0.0.0</tt:IPv4Address>
       </tt:Address>
       <tt:Port>0</tt:Port>
       <tt:TTL>0</tt:TTL>
       <tt:AutoStart>false</tt:AutoStart>
   </tt:Multicast>
   <tt:SessionTimeout>PT120S</tt:SessionTimeout>
</tt:MetadataConfiguration>
```

parameter	Support Status	Description
PTZStatus	No	Return error if specified
Events	Yes	If not specified, all events are notified。
Analytics	Yes	Cameras that support the Analytics Service can choose whether to use it or not.

MetadataStream, see Chapter 15 Metadata Stream.

Application Note For i-PRO Network Camera

# 6.2.7. Audio Back Channel Configuration

Bi-directional audio is supported on the basis of Back Channel Connection added to ONVIF Core Specification Ver.2.0.

Available audio codec depends on the setting of the browser. The following table shows the audio codec that will be informed by AudioDecoderConfigurationOptions. Initial setting of the codec is G.711.

Native setting		Onvif
Audio setting	Codec setting	AudioDecoderConfiguraionOptions
		Audio codec
OFF (initial)	NA.	G711 – 64 kbps
Option other than OFF	G711	G711 – 64 kbps
	G726 - 16kbps	G726 – 16 kbps
	G726 - 32kbps	G726 – 32 kbps
	AAC-LC - 64kbps <sup>2</sup>	G726 – 32 kbps

The camera accepts no tag or www.onvif.org/ver20/HalfDuplex/Auto for SendPrimacy the parameter of AudioOutputConfiguration. In the case of www.onvif.org/ver20/HalfDuplex/Auto the setting of the browser goes on to bidirectional, then the setting of the audio codec is set to G.726. Audio Back Channel overHTTP is not supported.
## 6.2.8."Quality" Parameter

The value 0 means "Low" in quality in ONVIF while "Super Fine" in browser. The relationship between these numbers is as shown in the table below.

"VideoEncoderConfigurat	" <i>Image quality"</i> (Native setting)
ion.Quality	
0	9 Low
1	8
2	7
3	6
4	5 Normal
5	4
6	3
7	2
8	1 Fine
9	0 Super Fine

Please refer to chapter 13.2.8 "Quality" Parameter for a comparison table for models compatible with Media 2.

#### 6.2.9."Rotate" Parameter

Aspect ratio (Native) (ONVIF)VideoSourceConfiguration.Extension		
4:3	Only vertical rotation (Degree=0/180)	
16:0	Can rotate	
10.9	(Degree=0/90/180/270)	

## 6.2.10. Analytics Configuration

There are three AnalyticsConfigurations for cameras except for multi-sensor cameras.

Multi-sensor cameras have an AnalyticsConfiguration associated with Ch1~4 of the VideoSourceConfiguration. Different connections VideoSourceConfiguration between and AnalyticsConfiguration are not allowed.

	VideoSourceConfiguration.token	AnalyticsConfiguration.token
Ch1	VideoSourceConfig	AnalyticsConfig
Ch2	VideoSourceConfig2	AnalyticsConfig2
Ch3	VideoSourceConfig3	AnalyticsConfig3
Ch4	VideoSourceConfig4	AnalyticsConfig4

Once the Profile is associated with Metadata Configuration and Analytics Configuration, Metadata is ready to use.

See Chapter 15 for information on how to use the Metadata Stream.

# 6.3.OSD

#### 6.3.1.Maximum number of OSD

Our camera has maximum two OSDs. These numbers can be gotten with GetOSDConfigulationOptions.

MaximumNumberOfOSDs	number
Total	2
PlainText	1
DateAndTime	1

#### 6.3.2.Position

Available OSD display position is following four types defined in ONVIF standard.

```
"UpperLeft"
"UpperRight"
"LowerLeft"
"LowerRight"
```

Free position is not supported with use of Custom.

# 6.4. VideoSourceMode

The WV-SUD638 series automatically reboots when *FramerateLimit* is switched to 30fps or 25fps using SetVideoSourceMode(). Other models do not restart.

# 7. Streaming

## 7.1. Session Management

Each single session is related to the sessionID of RTSP method. The session is controlled by the SessionID in SETUP of RTSP.

When a client SETUP and PLAY to control audio and video separately the client can use it with different session ID in SETUP. In this case two sessions are consumed.

## 7.2. Framerate

Regarding JPEG streaming use of RTPoverRTSP and RTPoverRTSPoverHTTP in transport layer causes the camera to drop its performance. So it may stream less than user specified framerate. In case that H.264 streaming is valid, JPEG framerate will be 5 fps.

# 7.3. Back Channel Connection

Supported Transport: UDP, RTP over RTSP.

We recommend that audio packet interval for client should be set to the same value as the setting of browser. In the case of RTP over RTSP, the interval of the audio packet should be at least the following value because of the buffer size. Our recommendation value for "RTP over RTSP" is 160ms and 320ms.

native setting	Client
Audio output interval	Audio packet interval (millisec)
160ms	160
320ms	160 - 320
640ms (initial)	160 - 640
1280ms	160 - 1280

The session for Audio Back Channel should be set separately from Audio/Video session because the back channel will be disconnected in five minutes(\*) by camera in order not to hold the session for a long time. (\*) It depends the setting of "Audio output duration" from browser.(1min – 1hour)



Video	Audio	AudioBack	
Session A		Session B	
Connection			

The following is the sequence of the audio back channel.

After 5 minutes of AudioBackChannel, the BackChannel session will be closed from camera. So the client should start a new session for AudioBackChannel from SETUP method.



# 7.4. Relationship with Cropping feature

Some cameras are supporting cropping feature, but ONVIF interface is not supported. If a client want to control the streaming for cropped view, cgi interface is available. In ONVIF interface, cropping feature is not recommended because unexpected image may be sent.

## 7.5. Network failure trigger base SD backup

The method to record to the SD card when a network failure is detected is as follows.

- 1. Use the CGI interface to set the validity period of the SD card recording function for network failure detection.
- Request an RTSP stream that contains the "sdbackup = yes" parameter during its lifetime. With this RTSP stream request, the camera will start detecting network failures, and when it detects a network failure, it will start recording the stream to the SD card.



Note:For more information on CGI, refer to the "IP Camera –Command Document".

# 8. PTZ Service

This camera supports "Generic" coordinate system.

The default profile has PTZConfiguration.

To control PTZ with a user profile, the client should add PTZConfiguration to the user profile.

Non-PTZ cameras (fixed cameras, omnidirectional cameras, multi-sensor cameras) support zooming from the browser, but do not support PTZ services.

Supported Space list:

kinds	Space	support
	http://www.onvif.org/ver10/tptz/PanTiltSpaces/PositionGenericSpace	Yes
	http://www.onvif.org/ver10/tptz/ZoomSpaces/PositionGenericSpace	Yes
Absolute	http://www.onvif.org/ver10/tptz/PanTiltSpaces/SphericalPositionSpace	No
	http://www.onvif.org/ver10/tptz/ZoomSpaces/PositionSpaceMillimeter	No
	http://www.onvif.org/ver10/tptz/ZoomSpaces/NormalizedDigitalPosition	No
	http://www.onvif.org/ver10/tptz/PanTiltSpaces/TranslationGenericSpace	Yes
Relative	http://www.onvif.org/ver10/tptz/ZoomSpaces/TranslationGenericSpace	Yes
	http://www.onvif.org/ver10/tptz/PanTiltSpaces/TranslationSpaceFov	No
	http://www.onvif.org/ver10/tptz/PanTiltSpaces/VelocityGenericSpace	Yes
Continuous	http://www.onvif.org/ver10/tptz/ZoomSpaces/VelocityGenericSpace	Yes
	http://www.onvif.org/ver10/tptz/PanTiltSpaces/VelocitySpaceDegrees	No
Speed	http://www.onvif.org/ver10/tptz/PanTiltSpaces/GenericSpeedSpace	Yes
	http://www.onvif.org/ver10/tptz/ZoomSpaces/ZoomGenericSpeedSpace	Yes
	http://www.onvif.org/ver10/tptz/PanTiltSpaces/SpeedSpaceDegrees	No
	http://www.onvif.org/ver10/tptz/ZoomSpaces/SpeedSpaceMillimeter	No

## 8.1. Use case of PTZ

#### 8.1.1.Set PTZ configuration

- 1. Choose MediaProfile to control PTZ .
- 2. Add PTZ Configuration to the MediaProfile if the profile doesn't have one.
  - Find available PTZConfiguration (GetPTZConfigurations)
  - Add one to MediaProfile (Media::AddPTZConfiguration, Media2::AddConfiguration)
- 3. Set PTZ Configuration
  - Find available node (GetNodes)
  - Check configurable parameters and their ranges (GetConfigurationOptions)
  - Set the configuration (SetConfiguration)

#### 8.1.2.PTZ control

- 1. Move to absolute position
  - Confirm default coordinate space of the PTZ Configuration
  - Move the absolute position of the coordinate apace (AbsoluteMove)
- 2. Move continuously
  - Move continuously with velocity of the coordinate space (ContinuousMove)
  - Stop (Stop)

## 8.1.3.Home Position

As default, camera doesn't have home position, so a client have to set the Home position beforehand. The last number of the Preset number is reserved for the Home position.

#### 8.1.4.Zoom

For a WV-SUD638 series supporting 1,080x zoom a client can control until 999.9x zoom by ONVIF interface.

For WV-SUD638 series, WV-X6500 Series WV-S6500 Series and WV-S6100 Series the Zoom range varies depending on the Native setting below.

- Digital zoom
- HD Extra optical zoom

To obtain and change the Native setting, refer to the "Command Document (H.265 supported models)".

Within the *XRange.Max* range of the AbsoluteZoomPositionSpace or *ReLativeZoomTransLationSpace*, the Zoom magnification can be specified using *GetConfigurationOptions()* or *GetNodes()*.

In the WV-SUD638 Series, WV-X6500 Series, WV-S6500 Series and WV-S6100 Series, *XRange.Max* is less than 1.

The maximum zoom ratio that can be specified with *AbsoluteMove* and *RelativeMove* is defined as follows:

Models	Digital zoom	HD Extra optical zoom	The maximum range of zoom
	Off	Off	0.02778
WV-SUD638 Series	On	Off	0.04167
	On	On	1
WV-X6500 Series	Off	Off	0.0625
WV-S6500 Series	On	Off	0.09375
WV-S6100 Series	On	On	1
Other models:	Any	Any	1

The Zoom range for models other than the WV-SUD638 series, WV-X6500 Series WV-S6500 Series and WV-S6100 Series is fixed at 0-1.

[Digital zoom] and [HD Extra optical zoom] can be found in the [Cam. Function] tab of the "PTZ" page.

Application Note For i-PRO Network Camera

### 8.1.5.Wiper, Washer, IR-LED

Wiper control · washer control · IR-LED control can be performed using SendAuxiliaryCommand(). It is possible to input the character string obtained by GetNodes() or GetCapabilityes() of PTZService. The relationship with Native CGI control is as follows:

i-Pro Native CGI (wiper) AuxiliaryData (ONVIF)		Description	
wiper=high	tt:Wiper On	Keep wiping fast	
wiper=low	tt:Wiper Low	Keep wiping slowly	
wiper=off	tt:Wiper Off	Stop the wiper	
wiper=1shot	tt:Wiper 1shot	Move wiper only once	
wiper=with_washer	tt:WasherProcedure On	Start the washer	
wiper=off	tt:WasherProcedure Off	Stop the washer	
ir_led_sync=Off	tt:IRLamp Off	Turn off IR LED Light	
ir_led_sync=AutoH	tt:IRLamp Auto	Set IR LED Light to Auto (High)	
ir_led_sync=AutoH	tt:IRLamp Auto_High	Set IR LED Light to Auto (High)	
ir_led_sync=AutoM	tt:IRLamp Auto_Mid	Set IR LED Light to Auto (Mid)	
ir_led_sync=AutoL	tt:IRLamp Auto_Low	Set IR LED Light to Auto (Low)	

#### 8.1.5.1. How to switch "Day & Night (IR)" of native Setting with ONVIF

To switch "Day & Night (IR)" of native Setting with ONVIF, please send two commands as follows:

- 1. Please set the values in the table below to AuxiliaryData and send SendAuxiliaryCommand.
- 2. Please set the values in the table below to IrCutFilter and send SetImagingSettings().

Please send in order of 1 and 2

For example, to set "Day & Night (IR)" to "Auto 2"

First set 'tt: IRLamp | Auto\_High' to AuxiliaryData of PTZService and send SendAuxiliaryCommand(). Next, set IrCutFilter of ImagingSettings to "AUTO" and send SetImagingSettings().

Native setting	ONVIF PTZService	ONVIF ImagingService.	note	
Day & Night(IR)	1) AuxiliaryData	2) ImagingSettings.IrCutFilter		
Off	(no need to set)	ON		
			In the case of "Day & Night	
On	(no need to set)	OFF	(electrical)", IrCutFilter =	
		OFF	OFF setting is ignored by	
			the camera.	
Auto1(Normal)	tt:IRLamp Off	AUTO		
Auto2(IR Light)	tt:IRLamp Auto			
	tt:IRLamp Auto_High			
	tt:IRLamp Auto_Mid	AUTO		
	tt:IRLamp Auto_Low			
Auto3(SCC)			Cannot set Auto3(SCC)	
	-	-	from ONVIF	

For Aero PTZ (WV-SUD638), set the relay output of the native setting to "Washer control".

Procedure:

- 1. Get the Day & Night(IR) status of Native setting.
- 2. Send SendAuxiLiaryCommand.
- 3. Get the Day & Night(IR) status of Native setting.
- 4. Send SetImagingSettings.
- 5. Get the *Day & Night(IR)* status of Native setting.

List of Day & Night(IR) sta	us of Native setting in each procedure
-----------------------------	--

1.[Day & Night(IR)]	2.SendAuxiliaryCommand	3.[Day & Night(IR)]	4. SetImagingSettings	5.[Day & Night(IR)]
	tt:IRLamp Off		IrCutFilter=ON(Day mode)	Off
			IrCutFilter=OFF(Night mode)	On
0#		0#	IrCutFilter=AUTO	Auto1(Nomal)
			IrCutFilter=ON(Day mode)	Off
	tt:IRLamp Auto		IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto2(IR Light)
	tt:IRLamp Off	On	IrCutFilter=ON(Day mode)	Off
			IrCutFilter=OFF(Night mode)	On
On			IrCutFilter=AUTO	Auto1(Nomal)
	tt:IRLamp Auto		IrCutFilter=ON(Day mode)	Off
			IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto2(IR Light)
	tt:IRLamp Off	Auto1(Nomal)	IrCutFilter=ON(Day mode)	Off
Auto1(Nomal)			IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto1(Nomal)
	tt:IRLamp Auto	Auto2(IR Light)	IrCutFilter=ON(Day mode)	Off
			IrCutFilter=OFF(Night mode)	On

1.[Day & Night(IR)]	2.SendAuxiliaryCommand	3.[Day & Night(IR)]	4. SetImagingSettings	5.[Day & Night(IR)]
			IrCutFilter=AUTO	Auto2(IR Light)
			IrCutFilter=ON(Day mode)	Off
	tt:IRLamp Off	Auto1(Nomal)	IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto1(Nomal)
Auto2(IR Light)			IrCutFilter=ON(Day mode)	Off
	tt:IRLamp Auto	Auto2(IR Light)	IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto2(IR Light)
	tt:IRLamp Off	Auto1(Nomal)	IrCutFilter=ON(Day mode)	Off
Auto3(SCC)			IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto1(Nomal)
	tt:IRLamp Auto	Auto2(IR Light)	IrCutFilter=ON(Day mode)	Off
			IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto2(IR Light)
	·		IrCutFilter=ON(Day mode)	Off
-		Auto3(SCC)	IrCutFilter=OFF(Night mode)	On
			IrCutFilter=AUTO	Auto3(SCC)

#### 8.1.6.Generic Space

#### 8.1.6.1. Pan range

The Pan range of Generic Space is 0 - 1 (0 - 360°). -1 - 1 (-180 - 180°) is not supported.

## 8.1.7.Speed settings

Speed support status varies by model.

Unsupported models: WV-SUD638 Series, WV-X6500 Series WV-S6500 Series and WV-S6100 Series Support models: Models other than the above:

# 9. Event service

# 9.1. Notification Events

Service	Туре	Topic Expression
Imaging	Motion Alarm	tns1:VideoSource/MotionAlarm
	Global Scene Change	tns1:VideoSource/GlobalSceneChange/ImagingService
DovicelO	Digital Input	tns1:Device/Trigger/DigitalInput
DeviceiO	Relay Output	tns1:Device/Trigger/Relay
PTZ	PresetTour status	tns1:PTZController/PTZPresetTours/Configuration
Soorah	Recording status	tns1:RecordingHistory/Recording/State
Search	Track status	tns1:RecordingHistory/Track/State
	Recording job state	tns1:RecordingConfig/JobState
	Recording configuration	tns1:RecordingConfig/RecordingConfiguration
Recording	Track configuration	tns1:RecordingConfig/TrackConfiguration
	Recording job	the 1- Recording Config/Recording Job Configuration
	configuration	
Modia2	Profile	tns1:Media/ProfileChanged
Mediaz	Configuration	tns1:Media/ConfigurationChanged
	Line Detector	tns1:RuleEngine/LineDetector/Crossed
Analytics	Field Detector	tns1:RuleEngine/FieldDetector/ObjectsInside
	Loitering Detector	tns1:RuleEngine/LoiteringDetector/ObjectIsLoitering
	Motion Region Detector	tns1:RuleEngine/MotionRegionDetector/Motion
	Line crossing counting	tns1:RuleEngine/CountAggregation/Counter

The following ONVIF standard events are supported.

i-PRO's unique events are shown below.

Туре	Topic Expression	
Command Alarm	tns1:UserAlarm/tnsipro1:Command/Received	
remaining capacity of	tns1:Device/tnsipro1:SD/Capacity/Decreased	
the SD memory card		
Direction Detector	tns1:RuleEngine/DirectionDetector/Moved	

### 9.2. The number of event registration

This camera allows up to 6 subscription for Pull-Point Notification and total 8 subscription for Basic Notification and Pull-Point Notification.

The subscription period is up to 7 days.

When a client restart the camera, all the "Subscribe" information is discarded.

This camera doesn't support ContentExpression.

#### 9.3. How to use event

Our camera supports some i-PRO specific events and ONVIF standard events. This chapter describes the usage of i-PRO events. The following is the namespace for the event;

xmlns:tnsipro1 = "http://i-pro.com/2021/onvif/event/topics"

#### 9.3.1.Terminal alarm

All of the terminals are set to Off by default. Onvif specification doesn't have the terminal enable command, so user have to the terminals enabled from alarm settings page of the browser.

For Terminal alarm the following topic is defined;

tns1:Device/Trigger/DigitalInput

Terminal number is described in InputToken in the event message.

Token	Terminal number
InputPort1	Terminal1
InputPort2	Terminal2
InputPort3	Terminal3

Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet">
<pre>tns1:Device/Trigger/DigitalInput</pre>
<wsnt:message></wsnt:message>
<tt:message propertyoperation="Initialized" utctime="2016-04-03T14:00:00Z"></tt:message>
<tt:source></tt:source>
<tt:simpleitem name="InputToken" value="InputPort1"></tt:simpleitem>
<tt:data></tt:data>
<tt:simpleitem name="LogicalState" value="true"></tt:simpleitem>

#### 9.3.2.Motion alarm

In order to use VMD alarm "Detection area" must be registered. These setting should be configured from native.

The following ONVIF standard event is supported;

```
tns1:VideoSource/MotionAlarm
```

Notifies "true" when motion is detected, and notifies "false" after 6 seconds.

If the operation continues for 6 seconds or more, the end of detection will be notified after the operation ends.

"true" = VMD detected

"false" = VMD detection finished

These events are notified only the first time of the motion detection as below.



Models that support the Analytics service also support the MotionRegionDetector event.

tns1:RuleEngine/MotionRegionDetector/Motion

MotionRegionDetector only notifies when motion detection starts, but not when it ends.

Initialized event is fixed to State="false"

Changed event is fixed to State="true"

#### 9.3.3.Command alarm

When the camera receives i-PRO original command alarm from other camera, event will be occurred. This function need to be configured from browser.

For Command alarm the following topic is defined;

tns1:UserAlarm/tnsipro1:Command/Received

### 9.3.4.Remaining capacity of the SD memory card

Remaining SD memory card capacity notification. Please refer to the Operating Instructions manual for settings.

For this alarm the following topic is defined;

tns1:Device/tnsipro1:SD/Capacity/Decreased

# 10. Recording Service

## 10.1. How to use

### 10.1.1. Activation for storage feature

The following is the usage without recording control service. In case of starting to record via Recoding control service, these changes which are the following 2) and 3) are automatically executed.

- Insertion of SD card
   For using storage feature, you need to firstly insert SD card.
- 2) Change of a encoding for recording to H.264
   Please change the setting of SD memory card from JPEG to H264 using the browser.
   Note: When the setting is changed SD card will be formatted.
- 3) Change of save mode to manual

Then please change the save trigger from alert to manual. To use only search or replay service, this step can be skipped.

Note: After executing SetSystemDeafultSettings these setting will be rollback.

# 10.2. Bitrate Limit and GovLength

The maximum number of bitrate for H.264 recording depends on models. Please refer to the operating instruction manual for detail. If the bitrate of video encoder configuration relating to the recording is more than max bitrate, it will be adjusted automatically when recording is started.

And GovLength may be changed to the value in such a way that at least one i-frame is in a second.

# 10.3. Recording procedure

- 1. GetRecordingToken with GetRecordings.
- 2. Create a RecordingJob by specifying Media Profile in CreateRecordingJob.
- 3. To start recording, specify "Active" for Mode in SetRecordingJobMode.
- 4. To stop recording, specify "Idle" for Mode in SetRecordingJobMode.
- 5. To delete a RecordingJob, call DeleteRecordingJob.

Configuration for Recording and Track are fixed values and cannot be changed.

The following commands are not supported:

- CreateRecording
- DeleteRecording
- CreateTrack
- DeleteTrack

## 10.4. Multi-sensor camera recording specifications

A multi-sensor camera holds as many RecordingTokens as there are lenses. However, since the specification is to record Ch1 to Ch4 simultaneously, only one RecordingJob is used.

# 11. Search Service

# 11.1. Search filter for FindEvent

To use Recording and track for Search filter they are needed to specify separately.

# 12. Replay Service

## 12.1. Replay Session

Camera support one replay session at a time. When receiving another replay request during replay, camera send 503 Service Unavailable.

## 12.2. Procedure for playing back recordings

- 1. Record in advance (Chapter 10.3).
- 2. To get a RecordingToken, use GetRecordings of the Recording Service.
- 3. To get the recording playback URL, specify RecordingToken in GetReplayURI of Replay service
- Make an RTSP connection Get RTSP DESCRIBE camera information RTSP SETUP Select receiving media Start RTSP PLAY delivery End RTSP TEARDOWN delivery

## 12.3. RTSP URL Format

The URL format for playback of the recording is as follows

rtsp://<ip>/ONVIF/Storage[/<ch>]

CH is supported only for multi-sensor cameras.

Audio redistribution is not performed with ONVIF format URLs.

# 12.4. RTSP Header

RTSP header	value	discription	support
Range	utc-time	Play range	yes
Seele	-1.0	Diau direction	Only "1,0" is
Scale	1.0	Play direction	supported
Speed	0.5	Speed control (Round when	Support in increments
Speed	0.5-	exceeding upper limit)	of 0.5
Pata Control	yes	free adjustment	yes
Rate-Control	no		
	intra		Only "all" is supported
Framas	intra/DIGIT	Frame transmission frequency	
Frames	predicted	setting	
	all		
Immediate	yes	sossion rosat	yes
	no	Session reset	
Require	onvif-replay	Fixed when playing with ONVIF	yes
Date	GMT Time	Time is specified as GMT	yes

The RTSP headers supported by the Replay distribution are as follows

# 13. Media2 Service

## 13.1. Profile

#### 13.1.1. Share Profile with ONVIF and native settings

Refer to the chapter "6.1.1 Share Profile with ONVIF and native settings".

# 13.1.1.1. Relationship between 'Setup/Image' of native setting and VideoencoderConfiguration.token of ONVIF.

The model sharing the setting with ONVIF and Native is defined in "6.1.1Share Profile with ONVIF and native settings".

#### Application Note For i-PRO Network Camera

# 13.1.1.2. Relationship between 'Setup / Image' of native setting and ONVIF setting items.

Refer to the chapter "6-1-1 Share Profile with ONVIF and native settings" and "6.1.2 Profile Name"

Native Setting	ONV/IE setting	Description	
JPEG (n)*	Old Vill Setting	Description	
	VideoEncoderCo		
Image capture size	nfiguration.Resol		
	ution		
	VideoEncoderCo		
Image quality	nfiguration.	See Chapter 6.2.8"Quality" Parameter	
	Quality		

As shown in the table below, the camera's existing settings and the ONVIF settings are linked

\*Setup > Image > JPEG (n)

Native setting		Description	
stream (n)*	ONVIF setting		
		If "Stream transmission" is set to "OFF" with Native setting,	
Stream		video is not delivered even with the ONVIF profile linked with	
transmission	-	NativeSetting's Stream.	
		At this time, the value of the ONVIF profile is NOT changed.	
Stream anading	VideoEncoder2Co		
Stream encoding	nfiguration.Encodi	1995 can be convined anti-videa Media Commission is used	
iormat	ng	H265 can be acquired only when Mediaz service is used	
	VideoEncoder2Co		
Image capture size	nfiguration.Resolut		
	ion		
	VideoEncoder2Co		
Transmission	nfiguration.RateCo	Settings can be changed only from Media 2	
priority	ntrol.	See 13.2.2.3 "ConstantBitRate" Parameter)	
	ConstantBitRate		
	VideoEncoder2Co		
Francis and	nfiguration.RateCo		
Frame rate	ntrol.FrameRateLi	See 6.2.2.2 "FramerateLimit" Parameter	
	mit.		
	VideoEncoder2Co		
Max bit rate (per	nfiguration.RateCo	See 6.2.2.1"BitrateLimit" Parameter	
client)	ntrol.BitrateLimit		
Image quality	VideoEncoder2Co	See 6.2.8"Quality" Parameter	

	nfiguration.Quality	
		If set from native, it will be reflected in the video delivered by
Smart Coding	-	ONVIF, but cannot be changed from ONVIF.
		See 6.2.5.2"GovLength" Parameter of Smart Coding
	VideoEncoder2Co	
Refresh interval	nfiguration ::	See 6.2.5"GovLength" Parameter
	GovLength	
		Multicast settings are independent for ONVIF configuration
Transmission type	Multicast	and native configuration.
		See 6.2.3"Multicast" Parameter

\* Setup > Image > stream (n)

#### 13.1.2. Profile Name

Refer to the chapter "6.1.2 Profile Name"

#### 13.1.3. Stream

13.1.3.1.The minimum guaranteed total number of encoder instancesIn Media2, use GetVideoEncoderInstances().

Refer to the chapter "6.1.3.1The minimum guaranteed total number of encoder instances"

#### 13.1.3.2. RTSP URL format

To get the URI of the RTSP connection, send *GetStreamUri()* specifying Profile. The URL format is as follows:

rtsp://<IP>/ONVIF/MediaInput?profile2=<ProfileToken>

## 13.2. Configuration

#### 13.2.1. Note for configuration changes

Refer to the chapter 6.

#### 13.2.2. "RateControl" Parameters

#### 13.2.2.1. "BitrateLimit" Parameter

Refer to the chapter 6.2.2.1"BitrateLimit" Parameter

#### 13.2.2.2. "FramerateLimit" Parameter

Refer to the chapter 6.2.2.2"FramerateLimit" Parameter

#### 13.2.2.3. "ConstantBitRate" Parameter

Set ConstantBitrate to false to set VBR. Set ConstantBitrate to true to set the frame rate.

Conditions under which frame rate, VBR, CBR can be set:

(ONVIF)/ ConstantBitRate	native	Configurable
True	Frame rate	yes
False	VBR	yes
-	CBR	-

#### 13.2.3. "Multicast" Parameter

Refer to the chapter 6.2.3"Multicast" Parameter

#### 13.2.4. "SessionTimeout" Parameter

Refer to the chapter 6.6.2.4"SessionTimeout" Parameter

#### 13.2.5. "GovLength" Parameter

#### 13.2.5.1. "GovLength" Parameter

Even in the case of H265, it rounds "GovLength" Parameter like Media1. Refer to the chapter 6.2.5.1"GovLength" Parameter of H.264

#### 13.2.5.2. "GovLength" Parameter of Smart Coding

Refer to the chapter 6.6.2.5.2"GovLength" Parameter of Smart Coding

#### 13.2.6. "Metadata" Configuration

Refer to the chapter 6.2.6Metadata Configuration.

### 13.2.7. "Audio Back Channel" Configuration

Refer to the chapter 6.2.7Audio Back Channel Configuration.

#### 13.2.8. "Quality" Parameter

When handling a model that supports only Media 1, refer to 6.2.8 "Quality" Parameter. Target Codecs:

- JPEG,
- H264,H265

(i-Pro Native setting) *Transmission priority*: VBR(i-Pro Native setting)

(ONVIF) ConstantBitrate= False

"Quality"(ONVIF)	"Image quality"(i-Pro Native setting)
0	9 Low
1	8
2	7
3	6
4	5 Normal
5	4
6	3
7	2
8	1 Fine
9	0 Super Fine

Target Codecs:

- H264,H265

(i-Pro Native setting) Transmission priority: Frame rate

(ONVIF) ConstantBitrate=true

(ONVIF)"Quality"	"Image quality" : (i-Pro Native setting)	
0		
1	Low(Motion priority)	
2		
3		
4		
5	Normai	
6		
7		
8	Fine(Image quality priority)	
9		

#### 13.2.9. "Rotate" Parameter

Refer to the chapter 6.2.9"Rotate" Parameter.

#### 13.2.10. Analytics Configuration

Refer to the chapter6.2.10Analytics Configuration .

## 13.3. OSD

#### 13.3.1. Maximum number of OSD

Refer to the chapter 6.3.1Maximum number of OSD.

## 13.4. VideoSourceMode

For models compatible with Media 2, reboot does not occur due to the change of VideoSourceMode.

# 14. Analytics Service

## 14.1. How to use

To use the Analytics Service, the camera must support Profile M. *i-VMD* does not support AnalyticsService. Refer to the Chapter II for more information. Extension Software does not work when the *image capture mode* is 60/50 fps or 15/12.5 fps.

# 14.2. List of supported functions

kind	Function	Requirem	AI-VMD	AI-VMD
		ent	(WV-XAE200W)	(WV-XAE300W*)
Analytics Module configuration	GetSupportedAnalyticsModules	М	Yes	Yes
	GetAnalyticsModules	М	Yes	Yes
	CreateAnalyticsModules	М	Yes	Yes
	DeleteAnalyticsModules	М	Yes	Yes
	GetAnalyticsModuleOptions	С	No	No
	ModifyAnalyticsModules	С	No	No
	GetSupportedMetadata	М	Yes	Yes
	GetSupportedRules	М	Yes	Yes
	GetRules	М	Yes	Yes
Rule	CreateRules	М	Yes	Yes
configuration	DeleteRules	М	Yes	Yes
	GetRuleOptions	С	Yes	Yes
	ModifyRules	С	Yes	Yes

List of ONVIF Analytics commands supported by the camera:

\* WV-XAE300W is AI-VMD/AI People Counting for 360-degree fisheye.

Requirement use the following abbreviations:

M: Mandatory, C: Conditional, O: Optional
# 14.3. Analytics Mudule Type and Rule Type

## 14.3.1. Kinds for Analytics Modules

After installing Extension Software's WV-XAE200W or "AI-VMD/AI People Counting for 360-degree fisheye(WV-XAE300W)", AI-VMD is tied to the following AnalyticsModule.Name.

List of AnalyticsModule Namesupported by the camera:				
"AnalyticsModule.Name"(ONVIF)	Ext. software (i-Pro Native setting)			
	AI-VMD			
	(WV-XAE200W)			
the ALL VMD and AlD a an la Counting	AI-VMD			
tt:AI-VMDandAiPeopleCounting	(WV-XAE300W)			

For multi-sensor cameras, "\_CH1/\_CH2/\_CH3/\_CH4" is added after the Rule.Name string.

## 14.3.2. Kinds for Rule

This chapter shows the Rules supported by the camera.

ONVIF standard rules:

"Rule.Name"(ONVIF)	AI-VMD functions (Native setting)	Reference
tt:FieldDetector	INTRUDER*3, Intruder detection*4	14.3.3
tt:LineDetector	CROSS LINE* <sup>3</sup> , Cross Line detection*4	14.3.4
tt:LoiteringDetector	LOITERING* <sup>3</sup> , Loitering detection* <sup>4</sup>	14.3.5
tt:MotionRegionDetector	VMD	14.3.6

Unique i-PRO Rules:

"Rule.Name"(ONVIF)	AI-VMD functions (Native setting)	Reference
tt:DirectionDetector	DIRECTION*3	14.3.7

<sup>&</sup>lt;sup>3</sup> To enable this function, please install Extension Software WV-XAE200W

<sup>&</sup>lt;sup>4</sup> To enable this function, please install Extension Software "AI-VMD/360 degree fisheye AI people counting (WV-XAE300W)"

## 14.3.3. FieldDetector

To use FieldDetector, please install Extension Software WV-XAE200W or "AI-VMD/360 degree fisheye AI people counting (WV-XAE300W)".

### 14.3.3.1. Rule definition

The definition of Rule is shown below.

```
<tt:RuleDescription Name="tt:FieldDetector" maxInstances="8">
<tt:Parameters>
<tt:SimpleItemDescription Name="ClassFilter" Type="tt:StringList" />
<tt:SimpleItemDescription Name="PresetToken" Type="tt:ReferenseToken"/>
<tt:ElementItemDescription Name="Field" Type="tt:Polygon" />
</tt:Parameters>
<tt:Messages IsProperty="false">
 <tt:Source>
  <tt:SimpleItemDescription Name="VideoSource" Type="tt:ReferenceToken" />
  <tt:SimpleItemDescription Name="AnalyticsConfiguration" Type="tt:ReferenceToken" /> <tt:SimpleItemDescription Name="Rule" Type="xs:string" />
 </tt:Source>
 <tt:Data>
  <tt:SimpleItemDescription Name="IsInside" Type="xs:boolean" />
  <tt:SimpleItemDescription Name="ObjectId" Type="tt:StringList" />
 </tt:Data>
 <tt:ParentTopic>tns1:RuleEngine/FieldDetector/ObjectsInside</tt:ParentTopic>
</tt:Messages>
</tt:RuleDescription>
```

parameter	value	Require ment	discription
ClassFilter	Human Bicycle Vehicle	0	Specify objects to be detected as a string list
PresetToken		С	ONVIF Preset Token Name of the preset with detection conditions set Only PTZ cameras are supported.
Field		М	Field with 4 to 16 vertices represented by coordinates (x.y) If out of range is specified, round to the nearest range

Requirement use the following abbreviations:

### 14.3.3.2. Event Notify Message

An example of Notify Message is shown below.

```
<wsnt:NotificationMessage>
 <wsnt:SubscriptionReference>
   <wsa:Address>http://192.168.0.10/Subscription?Idx=12345</wsa:Address>
 </wsnt:SubscriptionReference>
 <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet">tns1:
RuleEngine/FieldDetector/ObjectsInside</wsnt:Topic>
 <wsnt:Message>
   <tt:Message UtcTime="2016-03-17T17:00:00Z">
     <tt:Source>
       <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
       <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
       <tt:SimpleItem Name="Rule" Value="MyFieldDetector"/>
     </tt:Source>
     <tt:Data>
       <tt:SimpleItem Name="IsInside" Value="true">
       <tt:SimpleItem Name="ObjectId" Value="100 102 105">
     </tt:Data>
   </tt:Message>
 </wsnt:Message>
</wsnt:NotificationMessage>
```

SubscriptionReference only exists in Notify Messages.

## 14.3.3.3. MetadataStream>EventStream

An example Event Stream of Metadata is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<tt:MetaDataStream xmlns:tt="http://www.onvif.org/ver10/schema"
 xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"
 xmlns:xsd="http://www.w3.org/2001/XMLSchema">
 <tt:Event>
   <wsnt:NotificationMessage>
     <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"</pre>
       xmlns:tns1="http://www.onvif.org/ver10/topics">
   tns1: RuleEngine/FieldDetector/ObjectsInside
     </wsnt:Topic>
     <wsnt:Message>
       <tt:Message UtcTime="2016-03-17T17:00:00Z">
         <tt:Source>
           <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
           <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
           <tt:SimpleItem Name="Rule" Value="Rule2"/>
         </tt:Source>
         <tt:Data>
           <tt:SimpleItem Name="IsInside" Value="true"/>
           <tt:SimpleItem Name="ObjectId" Value="100 102 105"/>
           <tt:SimpleItem Name="ClassTypes" Value="Human"/>
           <tt:ElementItem Name="Image">
             <xsd:base64Binary>/9j//gBMAB (Omitted) v1/CgR//2Q==</xsd:base64Binary>
           </tt:ElementItem>
         </tt:Data>
       </tt:Message>
     </wsnt:Message>
   </wsnt:NotificationMessage>
  </tt:Event>
</tt:MetaDataStream>
```

Only the EventStream of the i-PRO original RTSP Stream (see Chapter 15.3) adds *CLassTypes* and *Image*.

If VideoAnalyticsConfiguration is specified in Profile, then AnalyticsConfiguration is appended.

parameter	value	Require ment	discription	
VideoSource		М	Token name of VideoSourceConfiguration	
AnalyticsConfigurati		0	Token name of the AnalyticsConfiguration	
Rule		М	Rule name (see chapter 14.4)	
ObjectId		0	ID number(s) of the object(s) to be detected	
leineide	true	NA	Elegindicating incide or outside	
ISIIISIUE	false	IVI		
	Human			
ClassTypes	Bicycle	С	Detection object	
	Vehicle			
Image		С	Base64 encoded JPEG image at the time of the event	

Requirement use the following abbreviations:

## 14.3.4. LineDetector

To use LineDetector, please install Extension Software WV-XAE200W or "AI-VMD/360 degree fisheye AI people counting (WV-XAE300W)".

### 14.3.4.1. Rule definition

The definition of Rule is shown below.

```
<tt:RuleDescription Name="tt:LineDetector" maxInstances="8">
  <tt:Parameters>
    <tt:SimpleItemDescription Name="Direction" Type="tt:Direction" />
    <tt:SimpleItemDescription Name="ClassFilter" Type="tt:StringList" />
    <tt:ElementItemDescription Name="Segments" Type="tt:Polyline" />
  </tt:Parameters>
  <tt:Messages>
   <tt:Source>
      <tt:SimpleItemDescription Name="VideoSource" Type="tt:ReferenceToken" />
     <tt:SimpleItemDescription Name="AnalyticsConfiguration" Type="tt:ReferenceToken" /> <tt:SimpleItemDescription Name="Rule" Type="xs:string" />
    </tt:Source>
   <tt:Data>
      <tt:SimpleItemDescription Name="ObjectId" Type="xs:integer" />
    </tt:Data>
    <tt:ParentTopic>tns1:RuleEngine/LineDetector/Crossed</tt:ParentTopic>
  </tt:Messages>
</tt:RuleDescription>
```

parameter	value	Requirem ent	discription	
Direction	Right Left Any	0	<ul><li>Indicates direction of detection.</li><li>Any refers to both directions.</li><li>For direction, see the explanation in chapter A.2 Line Detector in the Analytics specification of Service specifications.</li></ul>	
ClassFilter	Human Bicycle Vehicle	0	Specify the detection target with a string list	
PresetToken		С	Supports PTZ only. Indicates a preset token.	
Segments		М	Two points are indicated: the start point (x, y coordinates) and the end point (x, y coordinates).	

Requirement use the following abbreviations:

### 14.3.4.2. Event Notify Message

An example of Notify Message is shown below.

```
wsnt:NotificationMessage>
<wsnt:SubscriptionReference>
 <wsa:Address>http://192.168.0.10/Subscription?Idx=12345</wsa:Address>
</wsnt:SubscriptionReference>
<wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet">
 tns1:RuleEngine/LineDetector/Crossed
</wsnt:Topic>
<wsnt:Message>
 <tt:Message UtcTime="2016-03-17T17:00:00Z">
   <tt:Source>
     <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
     <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
     <tt:SimpleItem Name="Rule" Value="MyLineDetector"/>
   </tt:Source>
   <tt:Data>
     <tt:SimpleItem Name="ObjectId" Value="100">
     </tt:Data>
   </tt:Message>
 </wsnt:Message>
</wsnt:NotificationMessage>
```

SubscriptionReference only exists in Notify Messages.

## 14.3.4.3. MetadataStream>EventStream

An example Event Stream of Metadata is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<tt:MetaDataStream xmlns:tt="http://www.onvif.org/ver10/schema"
 xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"
 xmlns:xsd="http://www.w3.org/2001/XMLSchema">
 <tt:Event>
   <wsnt:NotificationMessage>
     <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"</pre>
       xmlns:tns1="http://www.onvif.org/ver10/topics">
 tns1:RuleEngine/LineDetector/Crossed
     </wsnt:Topic>
     <wsnt:Message>
       <tt:Message UtcTime="2016-03-17T17:00:00Z">
         <tt:Source>
           <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
           <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
           <tt:SimpleItem Name="Rule" Value="Rule1"/>
         </tt:Source>
         <tt:Data>
           <tt:SimpleItem Name="ObjectID" Value="100"/>
           <tt:SimpleItem Name="ClassTypes" Value="Human"/>
           <tt:ElementItem Name="Image">
             <xsd:base64Binary>/9j//gBMAB (Omitted) v1/CgR//2Q==</xsd:base64Binary>
           </tt:ElementItem>
         </tt:Data>
       </tt:Message>
     </wsnt:Message>
   </wsnt:NotificationMessage>
  </tt:Event>
</tt:MetaDataStream>
```

Only the EventStream of the i-PRO original RTSP Stream (see Chapter 15.3) adds *CLassTypes* and *Image*.

If VideoAnalyticsConfiguration is specified in Profile, then AnalyticsConfiguration is appended.

parameter	value	Require ment	discription	
VideoSource		М	Token name of VideoSourceConfiguration	
AnalyticsConfigurati on		0	Token name in AnalyticsConfiguration	
Rule		М	Rule name (see section14.4)	
ObjectId		0	ID number(s) of the object(s) to be detected	
ClassTypes	Human Bicycle Vehicle	С	Object to be detected	
Image		С	Base64-encoded JPEG image at the time the event occurred	

Requirement use the following abbreviations:

## 14.3.5. LoiteringDetector

To use LoiteringDetector, please install Extension Software WV-XAE200W or "AI-VMD/360 degree fisheye AI people counting (WV-XAE300W)".

### 14.3.5.1. Rule definition

The definition of Rule is shown below.

```
<tt:RuleDescription Name="tt:LoiteringDetector" maxInstances="8">
 <tt:Parameters>
   <tt:SimpleItemDescription Name="TimeThreshold" Type="xs:duration" />
   <tt:SimpleItemDescription Name="ClassFilter" Type="tt:StringList" />
   <tt:SimpleItemDescription Name="PresetToken" Type="tt:ReferenseToken" />
   <tt:ElementItemDescription Name="Field" Type="tt:Polygon" />
 </tt:Parameters>
 <tt:Messages IsProperty="false">
   <tt:Source>
     <tt:SimpleItemDescription Name="VideoSource" Type="tt:ReferenceToken" />
     <tt:SimpleItemDescription Name="AnalyticsConfiguration" Type="tt:ReferenceToken" />
     <tt:SimpleItemDescription Name="Rule" Type="xs:string" />
   </tt:Source>
   <tt:Data>
     <tt:SimpleItemDescription Name="ObjectId" Type="tt:StringList" />
     <tt:SimpleItemDescription Name="Since" Type="xs:dateTime" />
   </tt:Data>
   <tt:ParentTopic>tns1:RuleEngine/LoiteringDetector/ObjectIsLoitering</tt:ParentTopic>
 </tt:Messages>
</tt:RuleDescription>
```

parameter	value	Requirem ent	discription	
	PT10S			
	PT20S		Accept range of PT10S~PT120S(PT2M). If within the range,	
TimeThreshold	PT30S	М	round down to the nearest value	
	PT60S			
	PT120S			
	Human			
ClassFilter	Bicycle	0	Specify objects to be detected as a string list	
	Vehicle			
			ONVIF Preset Token Name of the preset with detection	
PresetToken		С	conditions set	
		Only PTZ cameras are supported.	Only PTZ cameras are supported.	
Field		0	Field with 4 to 16 vertices represented by coordinates (x.y)	
rieiù	riela O		If out of range is specified, round to the nearest range	

Requirement use the following abbreviations:

M: Mandatory, C: Conditional, O: Optional

Rounding of TimeThreshold settings

"Rule.Parameters.TimeThreshold"	[Loitering detecti	on time]
(ONVIF)	(i-Pro Native set	ting)
PT10S – PT19S	10sec	default setting
PT20S - PT29S	20sec	
PT30S - PT59S	30sec	
PT60S(PT1M) - PT119S	1min	
PT120S(PT2M)	2min	

### 14.3.5.2. Event Notify Message

An example of Notify Message is shown below.

```
<wsnt:NotificationMessage>
 <wsnt:SubscriptionReference>
   <wsa:Address>http://192.168.0.10/Subscription?Idx=12345</wsa:Address>
 </wsnt:SubscriptionReference>
 <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet">
tns1: RuleEngine/LoiteringDetector/ObjectIsLoitering
 </wsnt:Topic>
 <wsnt:Message>
   <tt:Message UtcTime="2016-03-17T17:00:00Z">
     <tt:Source>
       <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
       <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
       <tt:SimpleItem Name="Rule" Value="MyLoiteringDetector"/>
     </tt:Source>
     <tt:Data>
       <tt:SimpleItem Name="ObjectId" Value="100 102 105"/>
       <tt:SimpleItem Name="Since" Value="2016-03-17T16:50:00Z"/>
     </tt:Data>
   </tt:Message>
 </wsnt:Message>
</wsnt:NotificationMessage>
```

SubscriptionReference only exists in Notify Messages.

## 14.3.5.3. MetadataStream>EventStream

An example Event Stream of Metadata is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<tt:MetaDataStream xmlns:tt="http://www.onvif.org/ver10/schema"
 xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"
 xmlns:xsd="http://www.w3.org/2001/XMLSchema">
 <tt:Event>
   <wsnt:NotificationMessage>
     <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"</pre>
       xmlns:tns1="http://www.onvif.org/ver10/topics">
tns1: RuleEngine/LoiteringDetector/ObjectIsLoitering
     </wsnt:Topic>
     <wsnt:Message>
       <tt:Message UtcTime="2016-03-17T17:00:00Z">
         <tt:Source>
           <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
           <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
           <tt:SimpleItem Name="Rule" Value="Rule3"/>
         </tt:Source>
         <tt:Key>
         </tt:Key>
         <tt:Data>
           <tt:SimpleItem Name="ObjectId" Value="100 102 105"/>
           <tt:SimpleItem Name="Since" Value="2016-03-17T16:50:00Z"/>
           <tt:SimpleItem Name="ClassTypes" Value="Human"/>
           <tt:ElementItem Name="Image">
             <xsd:base64Binary>/9j//gBMAB (Omitted) v1/CgR//2Q==</xsd:base64Binary>
           </tt:ElementItem>
         </tt:Data>
       </tt:Message>
     </wsnt:Message>
   </wsnt:NotificationMessage>
  </tt:Event>
</tt:MetaDataStream>
```

Only the EventStream of the i-PRO original RTSP Stream (see Chapter 15.3 adds *CLassTypes* and *Image*.

If VideoAnalyticsConfiguration is specified in Profile, then *AnalyticsConfiguration* is appended.

parameter	value	Require ment	discription	
VideoSource		М	Token name of VideoSourceConfiguration	
AnalyticsConfigurati on		0	Token name of the AnalyticsConfiguration	
Rule		М	Rule name (see chapter 14.4)	
ObjectId		0	ID number(s) of the object(s) to be detected	
Since		М	Detection start time	
ClassTypes	Human Bicycle Vehicle	С	Detected object	
Image		С	Base64 encoded JPEG image at the time of the event	

Requirement use the following abbreviations:

## 14.3.6. MotionRegionDetector

MotionRegionDetector is enabled without installing Extension Software.

For details on how to set up motion detection, please refer to chapter 9.3.2Motion alarm.

### 14.3.6.1. Rule definition

The definition of Rule is shown below.

parameter	value	Require ment	discription
VideoSource	VideoSource	М	"VideoSource" fixed
RuleName		М	any string
State	ture	NA	Processes/absonce of detection
State	false		

Requirement use the following abbreviations:

### 14.3.6.2. Event Notify Message

An example of Notify Message is shown below.

```
<wsnt:NotificationMessage>
 <wsnt:SubscriptionReference>
   <wsa:Address>http://192.168.0.10/Subscription?Idx=12345</wsa:Address>
 </wsnt:SubscriptionReference>
 <wsnt:Topic
Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet">tns1:RuleEngine/MotionRegionD
etector/Motion</wsnt:Topic>
  <wsnt:Message>
   <tt:Message UtcTime="2016-03-17T17:00:00Z" PropertyOperation="Initialized">
     <tt:Source>
       <tt:SimpleItem Name="VideoSoruce" Value="VideoSource"/>
       <tt:SimpleItem Name="RuleName" Value="VmdRule1"/>
     </tt:Source>
     <tt:Data>
       <tt:SimpleItem Name="State" Value="true">
       </tt:Data>
     </tt:Message>
   </wsnt:Message>
 </wsnt:NotificationMessage>
```

SubscriptionReference only exists in Notify Messages.

### 14.3.6.3. MetadataStream>EventStream

An example Event Stream of Metadata is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<tt:MetaDataStream xmlns:tt="http://www.onvif.org/ver10/schema"
 xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"
 xmlns:xsd="http://www.w3.org/2001/XMLSchema">
 <tt:Event>
   <wsnt:NotificationMessage>
     <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"</pre>
xmlns:tns1="http://www.onvif.org/ver10/topics">tns1:RuleEngine/MotionRegionDetector/Motion</wsnt:T</pre>
opic>
     <wsnt:Message>
       <tt:Message UtcTime="2016-03-17T17:00:00Z" PropertyOperation="Initialized">
         <tt:Source>
           <tt:SimpleItem Name="VideoSoruce" Value="VideoSource"/>
           <tt:SimpleItem Name="RuleName" Value="VmdRule1"/>
         </tt:Source>
         <tt:Data>
           <tt:SimpleItem Name="State" Value="true"/>
         </tt:Data>
       </tt:Message>
     </wsnt:Message>
   </wsnt:NotificationMessage>
  </tt:Event>
</tt:MetaDataStream>
```

parameter	value	Requirement	discription
VideoSource	VideoSource	М	"VideoSource" fixed
RuleName		М	Rule name (see section 14.4)
State	ture false	М	true: detected / false: not detected

Requirement use the following abbreviations:

## 14.3.7. DirectionDetector

To use DirectionDetector, please install Extension Software WV-XAE200W.

### 14.3.7.1. Rule definition

The definition of Rule is shown below.

```
<tt:RuleDescription Name="tt:DirectionDetector" maxInstances="8">
  <tt:Parameters>
    <tt:SimpleItemDescription Name="TimeThreshold" Type="xs:duration" />
   <tt:SimpleItemDescription Name="Direction" Type="xs:string" />
   <tt:SimpleItemDescription Name="ClassFilter" Type="tt:StringList" /> <tt:SimpleItemDescription Name="PresetToken" Type="tt:ReferenseToken" />
   <tt:ElementItemDescription Name="Field" Type="tt:Polygon" />
  </tt:Parameters>
 <tt:Messages IsProperty="false">
   <tt:Source>
      <tt:SimpleItemDescription Name="VideoSource" Type="tt:ReferenceToken" />
     <tt:SimpleItemDescription Name="AnalyticsConfiguration" Type="tt:ReferenceToken" />
     <tt:SimpleItemDescription Name="Rule" Type="xs:string" />
   </tt:Source>
    <tt:Data>
     <tt:SimpleItemDescription Name="ObjectId" Type="tt:StringList" />
      <tt:SimpleItemDescription Name="Direction" Type="xs:string" />
   </tt:Data>
   <tt:ParentTopic>tns1:RuleEngine/DirectionDetector/Moved</tt:ParentTopic>
  </tt:Messages>
</tt:RuleDescription>
```

parameter	value	Requirement	discription	
TimeThreshold	PT1S PT2S PT3S PT4S PT5S PT10S	М	Error outside the range from PT1S to PT10S Truncate to nearest value within range	
Direction	Up Upper right Right Lower Right Lower Lower left Left Upper left	М	Detection direction	
ClassFilter	Human Bicycle Vehicle	0	Specify a list of strings representing objects to be detected	
PresetToken		С	ONVIF Preset Token name of the preset with detection conditions Supported only for PTZ cameras	
Field		М	Field with 4 to 16 vertices represented by coordinates (x.y) If out of range is specified, round to the nearest range	

Requirement use the following abbreviations:

M: Mandatory, C: Conditional, O: Optional

Rounding of TimeThreshold settings

"Rule.Parameters.TimeThreshold"	[Direction detection time]	
(ONVIF)	(i-Pro Native setting)	
DT10	1000	AI-VMD
F113	1sec	
PT2S	2sec	
PT3S	3sec	
PT4S	4sec	
PT5S~PT9S	5sec	
PT10S	10sec	

### 14.3.7.2. Event Notify Message

An example of Notify Message is shown below.

```
<wsnt:NotificationMessage>
 <wsnt:SubscriptionReference>
   <wsa:Address>http://192.168.0.10/Subscription?Idx=12345</wsa:Address>
 </wsnt:SubscriptionReference>
 <wsnt:Topic
Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet">tns1:RuleEngine/DirectionDete
ctor/Moved</wsnt:Topic>
  <wsnt:Message>
   <tt:Message UtcTime="2016-03-17T17:00:00Z">
     <tt:Source>
       <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
       <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig "/>
       <tt:SimpleItem Name="Rule" Value="MyDirectionDetector"/>
     </tt:Source>
     <tt:Data>
       <tt:SimpleItem Name="ObjectId" Value="100 102 105" />
       <tt:SimpleItem Name="Direction" Value="Up" />
     </tt:Data>
   </tt:Message>
 </wsnt:Message>
</wsnt:NotificationMessage>
```

SubscriptionReference only exists in Notify Messages.

### 14.3.7.3. MetadataStream>EventStream

An example Event Stream of Metadata is shown below.

```
<?xml version="1.0" encoding="UTF-8"?>
<tt:MetaDataStream xmlns:tt="http://www.onvif.org/ver10/schema"
 xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"
 xmlns:xsd="http://www.w3.org/2001/XMLSchema">
 <tt:Event>
   <wsnt:NotificationMessage>
     <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"</pre>
       xmlns:tns1="http://www.onvif.org/ver10/topics">
tns1:RuleEngine/DirectionDetector/Moved
     </wsnt:Topic>
     <wsnt:Message>
       <tt:Message UtcTime="2016-03-17T17:00:00Z">
         <tt:Source>
           <tt:SimpleItem Name="VideoSoruce" Value="VideoSourceConfig"/>
           <tt:SimpleItem Name="AnalyticsConfiguration" Value="AnalyticsConfig"/>
           <tt:SimpleItem Name="Rule" Value="Rule4"/>
         </tt:Source>
         <tt:Data>
           <tt:SimpleItem Name="ObjectId" Value="100 102 105" />
           <tt:SimpleItem Name="Direction" Value="Up" />
           <tt:SimpleItem Name="ClassTypes" Value="Human" />
           <tt:ElementItem Name="Image">
             <xsd:base64Binary>/9j//gBMAB (Omitted) v1/CgR//2Q==</xsd:base64Binary>
           </tt:ElementItem>
         </tt:Data>
       </tt:Message>
     </wsnt:Message>
   </wsnt:NotificationMessage>
  </tt:Event>
</tt:MetaDataStream>
```

Only the EventStream of the i-PRO original RTSP Stream (see Chapter 15.3) adds *CLassTypes* and *Image*.

If VideoAnalyticsConfiguration is specified in Profile, then AnalyticsConfiguration is appended.

parameter	value	Requirement	discription	
VideoSource		М	Token name of VideoSourceConfiguration	
AnalyticsConfiguration		0	Token name of the AnalyticsConfiguration	
Rule		М	Rule name (see chapter 14.4)	
ObjectId		0	ID number(s) of the object(s) to be detected	
	Up			
	Upper			
	right			
	Right	Μ		
Direction	Lower		Detection direction	
Direction	Right			
	Lower			
	Lower left			
	Left			
	Upper left			
	Human			
ClassTypes	Bicycle	С	Detected object	
	Vehicle			
Imaga		C	Base64 encoded JPEG image at the time of the	
IIIIaye			event	

Requirement use the following abbreviations:

# 14.4. RuleName naming rule

# 14.5. Fixed camera, multi-sensor camera

classification	RuleName
AI-VMD(8 areas)	Rule1 to Rule 8
VMD(4 areas)	VmdRule1 to VmdRule 4

The naming rule for Al multi-sensor shall be the same as above. Ch identification is done from VideoSourceConfiguration Token.

## 14.5.1. PTZ camera

preset	regions	RuleName	
	Outside preset (1)	Rule1 to Rule 8	
AI-VIND(8 areas)	Presets (16)	Rule1_PR1 to Rule8_PR16	
VMD(4 areas)	Outside preset (1)	VmdRule1 to VmdRule4	
	Presets (16)	VmdRule1_PR1 to VmdRule4_PR16	

Rule can be set for each of 17 positions.= 16 (preset) + 1 (not preset)

# 15. Metadata Stream

# 15.1. Metadata Stream Format

The format of the ONVIF MetadataStream can be found in metadatastream.xsd under Data format specifications in Network Interface Specifications.

See Chapters 14.3.3FieldDetector to 14.3.7DirectionDetector for AI-VMD EventStream examples.

# 15.2. ONVIF RTSP Stream

In this document, an RTSP connection via a URL that can be obtained from ONVIF *GetStreamUri()* is referred to as an RTSP Stream in ONVIF.

Some events only support RTSP Stream of i-PRO original RTSP Stream.

## 15.2.1. MetadataStream support status list

MetadataStream	nodes	AI-VMD	AI-VMD
		(WV-XAE200W)	(WV-XAE300W)
Analytics Stream	BoundingBox	Yes	Yes
	Object Classification	Yes	Yes

MotodotoStroom	Events	AI-VMD	AI-VMD
MetadataStream		(WV-XAE200W)	(WV-XAE300W)
	Field Detector	Yes	Yes
Event Stream	Line Detector	Yes	Yes
	Loitering Detector	Yes	Yes
	Direction Detector	Yes	No
	Motion Region Detector	Yes	Yes
	GlobalSceneChange	Yes	Yes
	AudioDetector	No*	No*

\* AudioDetector is supported only for i-PRO original RTSP Stream as described in Chapter 15.3.

# 15.2.2. MetadataStream distribution sequence



ONVIF RTSP Stream

### [Preconfiguration]

- 1. If AnalyticsConfiguration is not included in the Profile specified by *GetStreamUri()*, set AnalyticsConfiguration to the target Profile by AddConfiguration.
- 2. If the Analytics flag in the MetadataConfiguration of the Profile specified by *GetStreamUri()* is false, enable the Analytics flag in SetMetadataConfiguration.

#### [Steps]

- 1. get the URL with GetStreamUri()
- 2. include "vnd.onvif.metadata" in the response SDP of RTSP DESCRIBE
- 3. specify "Metadata(trackID=4)" in RTSP SETUP request
- 4. request RTSP PLAY
- 5. a MetadataStream (PayloadType=107) is sent

Metadata includes events issued by cameras and content detected by AI-VMD and extended apps.

# 15.3. i-PRO original RTSP Stream

In this document, the original method of streaming metadata (Analytics, Event Stream) directly with RTSP parameters is referred to as "i-PRO original RTSP Stream".

The metadata format is a proprietary extension of a portion of the ONVIF format.

URIs can be flagged for MetadataStream for delivery.

EventStream has no filtering capabilities. All events are sent.

Other than multi-sensor cameras:.

rtsp://<ip>(/Src)/MediaInput(/h264)/stream\_1?analytics=1&event=1

Multi-sensor cameras (Example for ch\_1)

rtsp://<ip>(/Src)/MediaInput(/h264)/stream\_1/ch\_1?analytics=1&event=1

Multi-sensor cameras (Example for ch\_2)

rtsp://<ip>(/Src)/MediaInput(/h264)/stream\_1/ch\_2?analytics=2&event=1

Example :

Key	value	discription
analytica	n (ob number)	Send AnalyticsStream.
anarytics	n ( ch humber )	The same number must be specified for channel and analytics.
f	1	Send EventStream

# 15.3.1. MetadataStream support status list

MetadataStream	nodes	AI-VMD	AI-VMD
		(WV-XAE200W)	(WV-XAE300W)
Analytics Stream	BoundingBox	Yes	Yes
	Object Classification	Yes	Yes

MotodotoStroom	Evente	AI-VMD	AI-VMD
wetauataStream	Events	(WV-XAE200W)	(WV-XAE300W)
	Field Detector	Yes	Yes
Event Stream	Line Detector	Yes	Yes
	Loitering Detector	Yes	Yes
	Direction Detector	Yes	No
	Motion Region Detector	Yes	Yes
	GlobalSceneChange	Yes	Yes
	AudioDetector	Yes	Yes

# 15.3.2. MetadataStream distribution sequence



i-PRO original RTSP Stream

### [Procedure]

- 1. make an RTSP connection by specifying a URL according to the i-PRO original RTSP Stream URL format
- 2. include "vnd.onvif.metadata" in the response SDP of RTSP DESCRIBE
- 3. specify Metadata(trackID=4) in RTSP SETUP request
- 4. request RTSP PLAY
- 5. MetadataStream(PayloadType=107) is sent

Appendix

# I. How to use Event service

# A) Receive push type events (WS-BaseNotification)

## i. Flow of receiving Motion Detect Event



## ii. Example of SOAP trace

### 1). GetEventProperties

```
<?xml version="1.0" encoding="utf-8"?>
<soap12:Envelope xmlns:soap12="http://www.w3.org/2003/05/soap-envelope"</pre>
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema"
xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsa="http://www.w3.org/2005/08/addressing"
xmlns:wsse="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-secext-1.0.xsd"
xmlns:wsu="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-utility-1.0.xsd">
  <soap12:Header>
   <wsa:Action
soap12:mustUnderstand="1">http://www.onvif.org/ver10/events/wsdl/EventPortType/GetEventPropertiesR
equest</wsa:Action>
   <wsa:MessageID>urn:uuid:299a2e0e-9a41-4aca-9dee-06d1ca916620</wsa:MessageID>
   <wsa:ReplyTo>
     <wsa:Address>http://www.w3.org/2005/08/addressing/anonymous</wsa:Address>
   </wsa:ReplyTo>
   <wsse:Security>
     <wsu:Timestamp wsu:Id="Time">
       <wsu:Created>2011-02-03T05:23:39Z</wsu:Created>
       <wsu:Expires>2011-02-03T05:23:49Z</wsu:Expires>
     </wsu:Timestamp>
     <wsse:UsernameToken wsu:Id="User">
       <wsse:Username>admin</wsse:Username>
       <wsse:Password Type="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-username-</pre>
token-profile-1.0#PasswordDigest">w8DYVj1hK4RyLcuLqyFV5GIzE00=</wsse:Password>
       <wsse:Nonce>yrgktV0w/kSlagnck00K6g==</wsse:Nonce>
       <wsu:Created>2011-02-03T05:23:39Z</wsu:Created>
     </wsse:UsernameToken>
   </wsse:Security>
   <wsa:To soap12:mustUnderstand="1">http://192.168.0.10/onvif</wsa:To>
  </soap12:Header>
  <soap12:Body>
   <GetEventProperties xmlns="http://www.onvif.org/ver10/events/wsdl" />
  </soap12:Body>
</soap12:Envelope>
```

### 2). GetEventPropertiesResponse

```
<?xml version="1.0" encoding="utf-8"?>
<env:Envelope xmlns:env="http://www.w3.org/2003/05/soap-envelope"</pre>
xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soap-
rpc" xmlns:xop="http://www.w3.org/2004/08/xop/include"
xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema"
xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1"
xmlns:tev="http://www.onvif.org/ver10/events/wsdl">
 <env:Header>
   <wsa:MessageID>urn:uuid:068e6052-1c36-13b2-9497-0080450da45b</wsa:MessageID>
   <wsa:RelatesTo>urn:uuid:3f5ae575-8f28-4ff0-b60f-36230574372b</wsa:RelatesTo>
   <wsa:To env:mustUnderstand="1">http://www.w3.org/2005/08/addressing/anonymous</wsa:To>
   <wsa:Action
env:mustUnderstand="1">http://www.onvif.org/ver10/events/wsd1/EventPortType/GetEventPropertiesResp
onse</wsa:Action>
  </env:Header>
  <env:Body>
   <GetEventPropertiesResponse xmlns="http://www.onvif.org/ver10/events/wsdl">
<TopicNamespaceLocation>http://www.onvif.org/onvif/ver10/topics/topicns.xml</TopicNamespaceLocatio
n>
     <wsnt:FixedTopicSet>true</wsnt:FixedTopicSet>
     <wstop:TopicSet xmlns:tns1="http://www.onvif.org/ver10/topics"xmlns:tnsipro1=" http://i-</pre>
pro.com/2021/onvif/event/topics">
       <tns1:VideoAnalytics>
         <tnsipro1:MotionDetector>
           <FigureChanged wstop:topic="true">
             <tt:MessageDescription IsProperty="false">
               <tt:Source>
                <tt:SimpleItemDescription Name="VideoAnalytics" Type="xsd:string" />
               </tt:Source>
               <tt:Data>
                <tt:SimpleItemDescription Name="Type" Type="xsd:string" />
               </tt:Data>
             </tt:MessageDescription>
           </FigureChanged>
         </tnsipro1:MotionDetector>
       </tns1:VideoAnalytics>
       <tns1:UserAlarm>
         <tnsipro1:Command>
           <Received wstop:topic="true">
             <tt:MessageDescription IsProperty="false">
               <tt:Source>
                <tt:SimpleItemDescription Name="Alarm" Type="xsd:string" />
              </tt:Source>
              <tt:Data>
                <tt:SimpleItemDescription Name="Type" Type="xsd:string" />
              </tt:Data>
             </tt:MessageDescription>
           </Received>
         </tnsipro1:Command>
       </tns1:UserAlarm>
       <tns1:Device>
         <tnsipro1:SD>
           <Capacity>
             <Decreased wstop:topic="true">
               <tt:MessageDescription IsProperty="false">
                <tt:Source>
                  <tt:SimpleItemDescription Name="Memory" Type="xsd:string" />
                </tt:Source>
                <tt:Data>
                  <tt:SimpleItemDescription Name="Capacity" Type="xsd:string" />
                </tt:Data>
              </tt:MessageDescription>
             </Decreased>
```

```
</Capacity>
         </tnsipro1:SD>
       </tns1:Device>
       <tns1:RecordingHistory>
         <Recording>
           <State wstop:topic="true">
             <tt:MessageDescription IsProperty="true">
              <tt:Source>
                <tt:SimpleItemDescription Name="RecordingToken" Type="tt:ReferenceToken" />
              </tt:Source>
              <tt:Data>
                <tt:SimpleItemDescription Name="IsRecording" Type="xsd:boolean" />
              </tt:Data>
             </tt:MessageDescription>
           </State>
         </Recording>
         <Track>
           <State wstop:topic="true">
             <tt:MessageDescription IsProperty="true">
              <tt:Source>
                <tt:SimpleItemDescription Name="RecordingToken" Type="tt:ReferenceToken" />
                <tt:SimpleItemDescription Name="Track" Type="tt:ReferenceToken" />
               </tt:Source>
              <tt:Data>
                <tt:SimpleItemDescription Name="IsDataPresent" Type="xsd:boolean" />
              </tt:Data>
             </tt:MessageDescription>
           </State>
         </Track>
       </tns1:RecordingHistory>
       <tns1:RecordingConfig>
         <JobState wstop:topic="true">
           <tt:MessageDescription IsProperty="true">
             <tt:Source>
               <tt:SimpleItemDescription Name="RecordingJobToken" Type="tt:ReferenceToken" />
             </tt:Source>
             <tt:Data>
              <tt:SimpleItemDescription Name="State" Type="xsd:stringn" />
               <tt:ElementItemDescription Name="Information"
Type="tt:RecordingJobStateInformation" />
             </tt:Data>
           </tt:MessageDescription>
         </JobState>
       </tns1:RecordingConfig>
       <tns1:VideoSource>
         <MotionAlarm wstop:topic="true">
           <tt:MessageDescription IsProperty="false">
             <tt:Source>
              <tt:SimpleItemDescription Name="VideoSourceToken" Type="tt:ReferenceToken" />
             </tt:Source>
             <tt:Data>
               <tt:SimpleItemDescription Name="State" Type="xsd:boolean" />
             </tt:Data>
           </tt:MessageDescription>
         </MotionAlarm>
       </tns1:VideoSource>
     </wstop:TopicSet>
<wsnt:TopicExpressionDialect>http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet</wsnt:Topi</pre>
cExpressionDialect>
     <wsnt:TopicExpressionDialect>http://docs.oasis-open.org/wsn/t-
1/TopicExpression/Concrete</wsnt:TopicExpressionDialect>
<MessageContentFilterDialect>http://www.onvif.org/ver10/tev/messageContentFilter/ItemFilter</Messa
geContentFilterDialect>
```

<MessageContentSchemaLocation>http://www.onvif.org/ver10/schema/onvif.xsd</MessageContentSchemaLoc</pre>

ation>
 </GetEventPropertiesResponse>
 </env:Body>
</env:Envelope>

#### 3). Subscribe

```
<?xml version="1.0" encoding="utf-8"?>
<soap12:Envelope xmlns:soap12="http://www.w3.org/2003/05/soap-envelope"</pre>
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema"
xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsa="http://www.w3.org/2005/08/addressing"
xmlns:wsse="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-secext-1.0.xsd"
xmlns:wsu="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-utility-1.0.xsd">
  <soap12:Header>
   <wsa:Action soap12:mustUnderstand="1">http://docs.oasis-open.org/wsn/bw-
2/NotificationProducer/SubscribeRequest</wsa:Action>
   <wsa:MessageID>urn:uuid:7ec8a56e-97c9-4484-9280-0de010f96306</wsa:MessageID>
   <wsa:ReplyTo>
     <wsa:Address>http://www.w3.org/2005/08/addressing/anonymous</wsa:Address>
   </wsa:ReplyTo>
   <wsse:Security>
     <wsu:Timestamp wsu:Id="Time">
       <wsu:Created>2011-02-03T05:31:00Z</wsu:Created>
       <wsu:Expires>2011-02-03T05:31:10Z</wsu:Expires>
     </wsu:Timestamp>
     <wsse:UsernameToken wsu:Id="User">
       <wsse:Username>admin</wsse:Username>
       <wsse:Password Type="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-username-</pre>
token-profile-1.0#PasswordDigest">1505c1Ejz054yS9r0Xwz+c3bNVA=</wsse:Password>
       <wsse:Nonce>E6vRIg7r00egXIwyYj31Pg==</wsse:Nonce>
       <wsu:Created>2011-02-03T05:31:00Z</wsu:Created>
     </wsse:UsernameToken>
   </wsse:Security>
   <wsa:To soap12:mustUnderstand="1">http://192.168.0.10/onvif</wsa:To>
  </soap12:Header>
  <soap12:Bodv>
   <Subscribe xmlns="http://docs.oasis-open.org/wsn/b-2">
     <ConsumerReference>
       <wsa:Address>http://192.168.0.111:10000/onvif/events</wsa:Address>
     </ConsumerReference>
     <Filter>
       <TopicExpression Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"
xmlns:tns1="http://www.onvif.org/ver10/topics">tns1:VideoSource/MotionAlarm</TopicExpression>
     </Filter>
     <InitialTerminationTime>PT10M</InitialTerminationTime>
   </Subscribe>
  </soap12:Body>
</soap12:Envelope>
```

#### 4). SubscribeResponse

<?xml version="1.0" encoding="utf-8"?> <env:Envelope xmlns:env="http://www.w3.org/2003/05/soap-envelope"</pre> xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchemainstance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soaprpc" xmlns:xop="http://www.w3.org/2004/08/xop/include" xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1"> <env:Header> <wsa:MessageID>urn:uuid:0119875c-d680-1419-9d13-00804559a33b</wsa:MessageID> <wsa:RelatesTo>urn:uuid:7ec8a56e-97c9-4484-9280-0de010f96306</wsa:RelatesTo> <wsa:To env:mustUnderstand="1">http://www.w3.org/2005/08/addressing/anonymous</wsa:To> <wsa:Action env:mustUnderstand="1">http://docs.oasis-open.org/wsn/bw-2/NotificationProducer/SubscribeResponse</wsa:Action> </env:Header> <env:Body> <wsnt:SubscribeResponse xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"> <wsnt:SubscriptionReference> <wsa:Address>http://192.168.0.10/onvif/Subscription?Idx=17818</wsa:Address> </wsnt:SubscriptionReference> <wsnt:CurrentTime>2011-02-03T05:36:52Z</wsnt:CurrentTime> <wsnt:TerminationTime>2011-02-03T05:46:52Z</wsnt:TerminationTime> </wsnt:SubscribeResponse> </env:Body> </env:Envelope>

### 5). Notify

<?xml version="1.0" encoding="utf-8"?> <env:Envelope xmlns:env="http://www.w3.org/2003/05/soap-envelope"</pre> xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchemainstance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soaprpc" xmlns:xop="http://www.w3.org/2004/08/xop/include" xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1" xmlns:tev="http://www.onvif.org/ver10/events/wsdl"> <env:Header> <wsa:MessageID>urn:uuid:502a7b53-1c35-13b2-9497-0080450da45b</wsa:MessageID> <wsa:To env:mustUnderstand="1">http://192.168.0.51:10000/onvif/events</wsa:To> <wsa:Action env:mustUnderstand="1">http://docs.oasis-open.org/wsn/bw-2/NotificationConsumer/Notify</wsa:Action> </env:Header> <env:Body> <wsnt:Notify> <wsnt:NotificationMessage> <wsnt:SubscriptionReference> <wsa:Address>http://192.168.0.20/onvif/Subscription?Idx=17972</wsa:Address> </wsnt:SubscriptionReference> <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"xmlns:tns1="http://www.onvif.o rg/ver10/topics" xmlns:tnsipro1=" http://ipro.com/2021/onvif/event/topics">tns1:VideoSource/MotionAlarm</wsnt:Topic> <wsnt:Message> <tt:Message UtcTime="2013-07-31T08:33:59Z"> <tt:Source> <tt:SimpleItem Name="VideoSourceToken" Value="3M" /> </tt:Source> <tt:Data> <tt:SimpleItem Name="State" Value="True" /> </tt:Data> </tt:Message> </wsnt:Message> </wsnt:NotificationMessage> </wsnt:Notify> </env:Body> </env:Envelope>

### 6). Renew

xml version="1.0" encoding="utf-8"?
<soap12:envelope <="" td="" xmlns:soap12="http://www.w3.org/2003/05/soap-envelope"></soap12:envelope>
<pre>xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema"</pre>
xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsa="http://www.w3.org/2005/08/addressing"
xmlns:wsse="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-secext-1.0.xsd"
<pre>xmlns:wsu="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-utility-1.0.xsd"&gt;</pre>
<soap12:header></soap12:header>
<wsa:action soap12:mustunderstand="1">http://docs.oasis-open.org/wsn/bw-</wsa:action>
2/SubscriptionManager/RenewRequest
<wsa:messageid>urn:uuid:6012ba9e-98b7-4cee-97f6-1d7fb7ef9b69</wsa:messageid>
<wsa:replyto></wsa:replyto>
<wsa:address>http://www.w3.org/2005/08/addressing/anonymous</wsa:address>
<wsse:security></wsse:security>
<wsu:timestamp wsu:id="Time"></wsu:timestamp>
<wsu:created>2011-02-03T05:31:18Z</wsu:created>
<wsu:expires>2011-02-03T05:31:28Z</wsu:expires>
<wsse:usernametoken wsu:id="User"></wsse:usernametoken>
<wsse:username>admin</wsse:username>
<wsse:password type="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-username-&lt;/td&gt;&lt;/tr&gt;&lt;tr&gt;&lt;td&gt;token-profile-1.0#PasswordDigest">A11MZDH7iYc1c821B1L1GXYSMUk=</wsse:password>
<wsse:nonce>cda1gOMjckWHsXZeCKrDTA==</wsse:nonce>
<wsu:created>2011-02-03T05:31:18Z</wsu:created>
<wsa:to soap12:mustunderstand="1">http://192.168.0.10/onvif/Subscription?Idx=17818</wsa:to>
<soap12:body></soap12:body>
<renew xmlns="http://docs.oasis-open.org/wsn/b-2"></renew>
<terminationtime>PT10M</terminationtime>

### 7). RenewResponse

<?xml version="1.0" encoding="utf-8"?> <env:Envelope xmlns:env="http://www.w3.org/2003/05/soap-envelope"</pre> xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchemainstance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soaprpc" xmlns:xop="http://www.w3.org/2004/08/xop/include" xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1"> <env:Header> <wsa:MessageID>urn:uuid:0119875e-d680-1419-9d13-00804559a33b</wsa:MessageID> <wsa:RelatesTo>urn:uuid:6012ba9e-98b7-4cee-97f6-1d7fb7ef9b69</wsa:RelatesTo> <wsa:To env:mustUnderstand="1">http://www.w3.org/2005/08/addressing/anonymous</wsa:To> <wsa:Action env:mustUnderstand="1">http://docs.oasis-open.org/wsn/bw-2/SubscriptionManager/RenewResponse</wsa:Action> </env:Header> <env:Body> <wsnt:RenewResponse xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"> <wsnt:TerminationTime>2011-02-03T05:47:09Z</wsnt:TerminationTime> <wsnt:CurrentTime>2011-02-03T05:37:09Z</wsnt:CurrentTime> </wsnt:RenewResponse> </env:Body> </env:Envelope>
### Application Note For i-PRO Network Camera

## 8). Unsubscribe

xml version="1.0" encoding="utf-8"?
<soap12:envelope <="" td="" xmlns:soap12="http://www.w3.org/2003/05/soap-envelope"></soap12:envelope>
<pre>xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema"</pre>
<pre>xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsa="http://www.w3.org/2005/08/addressing"</pre>
<pre>xmlns:wsse="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-secext-1.0.xsd"</pre>
<pre>xmlns:wsu="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-utility-1.0.xsd"&gt;</pre>
<soap12:header></soap12:header>
<wsa:action soap12:mustunderstand="1">http://docs.oasis-open.org/wsn/bw-</wsa:action>
2/SubscriptionManager/UnsubscribeRequest
<wsa:messageid>urn:uuid:efa87460-e34d-427f-b81d-eff21994b412</wsa:messageid>
<wsa:replyto></wsa:replyto>
<wsa:address>http://www.w3.org/2005/08/addressing/anonymous</wsa:address>
<wsse:security></wsse:security>
<wsu:timestamp wsu:id="Time"></wsu:timestamp>
<wsu:created>2011-02-03T05:31:24Z</wsu:created>
<wsu:expires>2011-02-03T05:31:34Z</wsu:expires>
<wsse:usernametoken wsu:id="User"></wsse:usernametoken>
<wsse:username>admin</wsse:username>
<wsse:password type="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-username-&lt;/td&gt;&lt;/tr&gt;&lt;tr&gt;&lt;td&gt;token-profile-1.0#PasswordDigest">PPh5+jImR39oFcrMDVHkw6KKGsI=</wsse:password>
<wsse:nonce>ADUm0HiQY023wB3WyB1HZA==</wsse:nonce>
<wsu:created>2011-02-03T05:31:24Z</wsu:created>
<wsa:to soap12:mustunderstand="1">http://192.168.0.10/onvif/Subscription?Idx=17818</wsa:to>
<soap12:body></soap12:body>
<unsubscribe xmlns="http://docs.oasis-open.org/wsn/b-2"></unsubscribe>

#### Application Note For i-PRO Network Camera

#### 9). UnsubscribeResponse

<?xml version="1.0" encoding="utf-8"?> <env:Envelope xmlns:env="http://www.w3.org/2003/05/soap-envelope"</pre> xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchemainstance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soaprpc" xmlns:xop="http://www.w3.org/2004/08/xop/include" xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1"> <env:Header> <wsa:MessageID>urn:uuid:0119875f-d680-1419-9d13-00804559a33b</wsa:MessageID> <wsa:RelatesTo>urn:uuid:efa87460-e34d-427f-b81d-eff21994b412</wsa:RelatesTo> <wsa:To env:mustUnderstand="1">http://www.w3.org/2005/08/addressing/anonymous</wsa:To> <wsa:Action env:mustUnderstand="1">http://docs.oasis-open.org/wsn/bw-2/SubscriptionManager/UnsubscribeResponse</wsa:Action> </env:Header> <env:Body> <wsnt:UnsubscribeResponse xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2"> </wsnt:UnsubscribeResponse> </env:Body> </env:Envelope>

# B) Get pull type events (Event service of ONVIF)

## i. Flow of receiving Motion Detect Event



## ii. Example of SOAP trace

#### 1). CreatePullPointSubscription

```
<?xml version="1.0" encoding="utf-8"?>
<soap12:Envelope xmlns:soap12="http://www.w3.org/2003/05/soap-envelope"</pre>
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema"
xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsa="http://www.w3.org/2005/08/addressing"
xmlns:wsse="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-secext-1.0.xsd"
xmlns:wsu="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-utility-1.0.xsd">
  <soap12:Header>
   <wsa:Action
soap12:mustUnderstand="1">http://www.onvif.org/ver10/events/wsdl/EventPortType/CreatePullPointSubs
criptionRequest</wsa:Action>
   <wsa:MessageID>urn:uuid:cca999f8-b0e1-4e4e-ac7e-04a074d49fbf</wsa:MessageID>
   <wsa:ReplyTo>
     <wsa:Address>http://www.w3.org/2005/08/addressing/anonymous</wsa:Address>
   </wsa:ReplyTo>
   <wsse:Security>
     <wsu:Timestamp wsu:Id="Time">
       <wsu:Created>2011-02-03T05:32:40Z</wsu:Created>
       <wsu:Expires>2011-02-03T05:32:50Z</wsu:Expires>
     </wsu:Timestamp>
     <wsse:UsernameToken wsu:Id="User">
       <wsse:Username>admin</wsse:Username>
       <wsse:Password Type="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-username-</pre>
token-profile-1.0#PasswordDigest">0FVLlgsnsY4Uebmes7iHn9Yw4Qk=</wsse:Password>
       <wsse:Nonce>tDGL/U0o8UiHlkd2QguF3A==</wsse:Nonce>
       <wsu:Created>2011-02-03T05:32:40Z</wsu:Created>
     </wsse:UsernameToken>
   </wsse:Security>
   <wsa:To soap12:mustUnderstand="1">http://192.168.0.10/onvif</wsa:To>
  </soap12:Header>
  <soap12:Body>
   <CreatePullPointSubscription xmlns="http://www.onvif.org/ver10/events/wsdl">
     <Filter>
       <TopicExpression Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"
xmlns="http://docs.oasis-open.org/wsn/b-2"
xmlns:tns1="http://www.onvif.org/ver10/topics">tns1:VideoSource/MotionAlarm</TopicExpression>
     </Filter>
     <InitialTerminationTime>PT10M</InitialTerminationTime>
   </CreatePullPointSubscription>
  </soap12:Body>
</soap12:Envelope>
```

## 2). CreatePullPointSubscriptionResponse

xml version="1.0" encoding="utf-8"?
<pre><env:envelope <="" pre="" xmlns:env="http://www.w3.org/2003/05/soap-envelope"></env:envelope></pre>
<pre>xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchema-</pre>
<pre>instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soap-</pre>
rpc" xmlns:xop="http://www.w3.org/2004/08/xop/include"
<pre>xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema"</pre>
<pre>xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1"&gt;</pre>
<env:header></env:header>
<wsa:messageid>urn:uuid:01198760-d680-1419-9d13-00804559a33b</wsa:messageid>
<wsa:relatesto>urn:uuid:cca999f8-b0e1-4e4e-ac7e-04a074d49fbf</wsa:relatesto>
<wsa:to env:mustunderstand="1">http://www.w3.org/2005/08/addressing/anonymous</wsa:to>
<wsa:action< td=""></wsa:action<>
<pre>env:mustUnderstand="1"&gt;http://www.onvif.org/ver10/events/wsdl/EventPortType/CreatePullPointSubscri</pre>
ptionResponse
<env:body></env:body>
<createpullpointsubscriptionresponse xmlns="http://www.onvif.org/ver10/events/wsdl"></createpullpointsubscriptionresponse>
<subscriptionreference></subscriptionreference>
<wsa:address>http://192.168.0.10/onvif/Subscription?Idx=399</wsa:address>
<wsnt:currenttime>2011-02-03T05:38:32Z</wsnt:currenttime>
<wsnt:terminationtime>2011-02-03T05:48:32Z</wsnt:terminationtime>

#### Application Note For i-PRO Network Camera

### 3). PullMessages

xml version="1.0" encoding="utf-8"?
<soap12:envelope <="" td="" xmlns:soap12="http://www.w3.org/2003/05/soap-envelope"></soap12:envelope>
<pre>xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema"</pre>
xmlns:tt="http://www.onvif.org/ver10/schema" xmlns:wsa="http://www.w3.org/2005/08/addressing"
<pre>xmlns:wsse="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-secext-1.0.xsd"</pre>
xmlns:wsu="http://docs.oasis-open.org/wss/2004/01/oasis-200401-wss-wssecurity-utility-1.0.xsd">
<pre><soan12:header></soan12:header></pre>
<pre></pre>
soan12 must linderstand="1" thtn://www.onvif.org/ver10/events/wsd1/PullPointSubscription/PullMessage
sRequests/wsa:Actions
<pre></pre>
<pre></pre>
/wsa.RanlyTox
with Timetamp with Id-"Time"
$\sqrt{10}$
(wsu.) Expines 2013 07 2170:56:0172/wsu.) Expines
<pre></pre>
(/wsg.ilmestamp/
(wsse.userillapharman)
(user Descured Turner "better (/desc. each open eng/use/2004/01/eacie 200401 user username
<pre><wsse:passworu type="http://uccs.oasis-open.org/wss/2004/01/0asis-200401-wss-userhame-&lt;br">takan wasfile 1.0Hpassword bioset "Add2CD10asic GVCooNTAKiCY200M / (vscorDecayand)</wsse:passworu></pre>
token-profile-i.0#PasswordDigest >4dG/CP18Fj+CjVCeanINICK3Qmm=
<pre><wsse: nonce="">vnclivngbcweJ/L5+iscug==</wsse:> </pre>
<pre><wsa:10 soapi2:mustunderstand="1">http://192.168.0.20/onvit/Subscription?idx=2104</wsa:10></pre>
<soap12:body></soap12:body>
<pullmessages xmlns="http://www.onvif.org/ver10/events/wsdl"></pullmessages>
<timeout>PT1S</timeout>
<pre><messagelimit>1</messagelimit></pre>

#### 4). PullMessagesResponse

```
<?xml version="1.0" encoding="utf-8"?>
<env:Envelope xmlns:env="http://www.w3.org/2003/05/soap-envelope"</pre>
xmlns:enc="http://www.w3.org/2003/05/soap-encoding" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns:rpc="http://www.w3.org/2003/05/soap-
rpc" xmlns:xop="http://www.w3.org/2004/08/xop/include"
xmlns:wsa="http://www.w3.org/2005/08/addressing" xmlns:tt="http://www.onvif.org/ver10/schema"
xmlns:wsnt="http://docs.oasis-open.org/wsn/b-2" xmlns:wstop="http://docs.oasis-open.org/wsn/t-1"
xmlns:tev="http://www.onvif.org/ver10/events/wsdl">
 <env:Header>
   <wsa:MessageID>urn:uuid:684fc9d2-1c38-13b2-9497-0080450da45b</wsa:MessageID>
   <wsa:RelatesTo>urn:uuid:c70fe246-0bd1-424a-abfa-6eab7bde8fd4</wsa:RelatesTo>
   <wsa:To env:mustUnderstand="1">http://www.w3.org/2005/08/addressing/anonymous</wsa:To>
   <wsa:Action
env:mustUnderstand="1">http://www.onvif.org/ver10/events/wsd1/PullPointSubscription/PullMessagesRe
sponse</wsa:Action>
  </env:Header>
  <env:Body>
   <PullMessagesResponse xmlns="http://www.onvif.org/ver10/events/wsdl">
     <CurrentTime>2013-07-31T08:56:08Z</CurrentTime>
     <TerminationTime>2013-08-01T00:00:00Z</TerminationTime>
     <wsnt:NotificationMessage>
       <wsnt:SubscriptionReference>
         <wsa:Address>http://192.168.0.20/onvif/Subscription?Idx=2104</wsa:Address>
       </wsnt:SubscriptionReference>
       <wsnt:Topic Dialect="http://www.onvif.org/ver10/tev/topicExpression/ConcreteSet"</pre>
xmlns:tns1="http://www.onvif.org/ver10/topics" xmlns:tnsipro1="http://i-
pro.com/2021/onvif/event/topics">tns1:VideoSource/MotionAlarm</wsnt:Topic>
       <wsnt:Message>
         <tt:Message UtcTime="2013-07-31T08:56:05Z">
           <tt:Source>
             <tt:SimpleItem Name="VideoSourceToken" Value="3M" />
           </tt:Source>
           <tt:Data>
             <tt:SimpleItem Name="State" Value="True" />
           </tt:Data>
         </tt:Message>
       </wsnt:Message>
     </wsnt:NotificationMessage>
   </PullMessagesResponse>
  </env:Body>
</env:Envelope>
```

# II. About i-VMD

# A) Analytics Service

i-VMD (WV-SAE200/WV-SAE200W) does not support Analytics Service. Therefore, AnalyticsConfiguration cannot be added to Profile.

### i. How to use

To send an AnalyticsStream using i-PRO original RTSP Stream, some preliminary preparations are required.

- 1) Installation of the Extension Software. in order to use the Analytics service, the Extension Software must be installed.
- 2) License registration. Register a license to use the extension software.
- 3) Time schedule registration. Register a time schedule for the enhanced software to operate according to the time period registered in the time schedule.

# B) Metadata Stream

### i. ONVIF RTSP Stream

#### MetadataStream Support Status List

See chapter 15.2.2MetadataStream distribution sequence for MetadataStream procedures.

MetadataStream	Nodes	i-VMD
Analytics Stream	BoundingBox	No
	Object Classification	No

MetadataStream	Events	i-VMD

	Object Detection	No
Event Stream	GlobalSceneChange	Yes
	AudioDetector	No

## ii. i-PRO original RTSP Stream

## MetadataStream Support Status List

See chapter 15.3.2MetadataStream distribution sequence for MetadataStream procedures.

MetadataStream	Nodes	i-VMD
Analytics Stream	BoundingBox	Yes
	Object Classification	No

MetadataStream	Events	i-VMD
Event Stream	Object Detection	No
	GlobalSceneChange	No
	AudioDetector	No